

mitsubishi

Digital-Analog Converter Module

User's Manual
(Hardware)

AJ65VBTCU-68DAVN

Thank you for buying the Mitsubishi general-purpose programmable logic controller MELSEC Series

Prior to use, please read both this manual and detailed manual thoroughly and familiarize yourself with the product.



MODEL	AJ65V-68DAN-U-HW
MODEL CODE	13JP20
IB(NA)-0800252-C(0612)MEE	

● SAFETY PRECAUTIONS ●

(Always read before starting use)

When using this equipment, thoroughly read this manual. Also pay careful attention to safety and handle the module properly.

These precautions apply only to this equipment.

Refer to the user's manual of the CPU module to use for a description of the PLC system safety precautions.


These "Safety Precautions" classify the safety precautions into two categories: "DANGER" and "CAUTION".



Procedures which may lead to a dangerous condition and cause death or serious injury, if not carried out properly.



Procedures which may lead to a dangerous condition and cause superficial to medium injury, or physical damage only, if not carried out properly.

Depending on circumstances, procedures indicated by  **CAUTION** may also be linked to serious results.

In any case, it is important to follow the directions for usage.

Store this manual in a safe place so that you can take it out and read it whenever necessary. Always forward it to the end user.

[DESIGN PRECAUTIONS]

DANGER

- Configure a safety circuit so that the safety of the overall system is maintained even when an external power error or PLC error occurs. Accident may occur due to output error or malfunctioning.
 - (1) The status of analog output changes depending on the setting of various functions that control the analog output. Take sufficient caution when setting for those functions.
For details of analog output status, refer to Section 3.4.1 "Combinations of functions in each part" in the User's Manual.
 - (2) Normal output may not be obtained due to malfunctions of output elements or the internal circuits.
Configure a circuit to monitor signals which may lead to a serious accident.

[DESIGN PRECAUTIONS]

⚠ CAUTION

- Do not bunch the control wires or communication cables with the main circuit or power wires, or install them close to each other.
They should be installed 100mm (3.9inch) or more from each other.
Not doing so could result in noise that would cause erroneous operation.
- At power ON/OFF, voltage or current may instantaneously be output from the output terminal of this module. In such case, wait until the analog output becomes stable to start controlling the external device.

[INSTALLATION PRECAUTIONS]

⚠ CAUTION

- Use each module in an environment as specified in the "general specification" in the detailed manual.
Using the PLC outside the range of the general specifications may result in electric shock, fire or malfunction, or may damage or degrade the module.
- Securely fix the module to a DIN rail or securely fix it with the CC-Link connector type fitting.
Not doing so can cause a drop or malfunction.
- Do not touch the conducted area of the module.
Doing so may cause module malfunctioning or breakdowns.

[WIRING PRECAUTIONS]

⚠ CAUTION

- Be sure to shut off all phases of the external power supply used by the system before installation or wiring.
Not doing so can cause the product to be damaged or malfunction.
- Always ground the FG pin to the protective ground conductor.
Not doing so can cause a malfunction.
- Wire the module correctly after confirming the rated voltage and pin layout of the product.
Not doing so can cause a fire or failure.
- Do not insert the one-touch connector plug for I/O of the one-touch connector type/connector type compact remote I/O unit into the one-touch connector for analog I/O accidentally.
Doing so can cause the module to be damaged.
- Ensure that no foreign matter such as chips and wire-offcuts enter the module.
Foreign matter can cause a fire, failure or malfunction.
- Always fit a non-wired, one-touch connector plug to the open one-touch connector for power supply/FG.
Not doing so can cause a failure or malfunction.

[WIRING PRECAUTIONS]

⚠ CAUTION

- When connecting the wires or cables to the module, always run them in conduits or clamp them.
Not doing so can damage the module and cables due to loose, moved or accidentally pulled cables or can cause a malfunction due to a cable connection fault.
- Do not install the control lines together with the communication cables, or bring them close to each other. Failure to do so may cause malfunctions due to noise.
- When disconnecting the communication and power supply cables from the module, do not hold and pull the cable part.
Disconnect the cables after loosening the screws in the portions connected to the module. Pulling the cables connected to the module can damage the module and cables or can cause a malfunction due to a cable connection fault.

[STARTING AND MAINTENANCE PRECAUTIONS]

⚠ CAUTION

- Do not touch the pin while the power is on. Doing so may cause malfunction.
- Be sure to shut off all phases of the external power supply used by the system before cleaning.
Not doing so can cause the module to fail or malfunction.
- Never disassemble or modify the module.
This may cause breakdowns, malfunctioning, injury and/or fire.
- Do not drop the module or give it hard impact since its case is made of resin.
Doing so can damage the module .
- Be sure to shut off all phases of the external power supply used by the system before mounting or dismounting the module to or from the panel.
Not doing so can cause the module to fail or malfunction.
- Always make sure to touch the grounded metal to discharge the electricity charged in the body, etc., before touching the module.
Failure to do so may cause a failure or malfunctions of the module.

[DISPOSAL PRECAUTIONS]

⚠ CAUTION

- When disposing of this product, treat it as industrial waste.

Revisions

* The manual number is noted at the lower right of the top cover.

Print Date	*Manual Number	Revision
Mar., 2003	IB(NA)-0800252-A	First printing
Jul., 2005	IB(NA)-0800252-B	Partial correction SAFETY PRECAUTIONS
Dec., 2006	IB(NA)-0800252-C	Partial correction Chapter 3, Chapter 8

This manual confers no industrial property rights or any rights of any other kind, nor does it confer any patent licenses. Mitsubishi electric Corporation cannot be held responsible for any problems involving industrial property rights which may occur as a result of using the contents noted in this manual.

© 2003 MITSUBISHI ELECTRIC CORPORATION

CONTENTS

1. Overview	1
2. Specification	1
2.1 Performance specifications	1
3. Names and setting of parts	3
4. Loading and Installation	6
4.1 Precautions when handling	6
4.2 Installation environment	6
5. Data Link Cable Wiring	7
5.1 Instructions for handling the CC-Link dedicated cables.....	7
5.2 Connection of the CC-Link dedicated cables	7
6. Wiring	9
6.1 Wiring precautions	9
6.2 Module connection example.....	9
7. How to Wire the One-Touch Connector Plug	10
8. External Dimension Diagram	12

About the Manuals

The following manuals are also related to this product.
Order them if necessary.

Detailed Manual

Manual name	Manual No. (Model code)
Digital-Analog Converter Module type AJ65VBTCU-68DAVN User's Manual	SH-080402E (13JR66)

Related Manual

Manual name	Manual No. (Model code)
Control & Communication Link System Master/Local Module type AJ61BT11/A1SJ61BT11 User's Manual	IB-66721 (13J872)
Control & Communication Link System Master/Local Module type AJ61QBT11/A1SJ61QBT11 User's Manual	IB-66722 (13J873)
Control & Communication Link System Master/Local Module type QJ61BT11N User's Manual	SH-080394 (13JR64)

Conformation to the EMC Directive and Low Voltage Instruction

When complying with EMC Directives and Low-Voltage Directives by assembling a Mitsubishi PLC compatible with EMC Directive and Low-Voltage Directives into the user product, refer to Chapter 3 "EMC Directives and Low-Voltage Directives" in the User's Manual (Hardware Section) for the CPU module being used. The CE logo is printed on the rating plate on the main body of the PLC that conforms to the EMC directive and low voltage instruction. To conform this product to the EMC Directive and Low Voltage Directive, refer to the Section of "CC-Link Modules" in Chapter 3 "EMC Directive and Low Voltage Directive" of the User's Manual (Hardware) of the CPU module used.

1. Overview

This user's manual explains the specifications, names and setting of parts, wiring and others of Type AJ65VBTCU-68DAVN digital-analog converter module (hereafter abbreviated to the "AJ65VBTCU-68DAVN") which is used as a remote device station of a CC-Link system.

Confirm if the following items are included in the package after unpacking.

Item name	Number of items
Digital-Analog Converter Module type AJ65VBTCU-68DAVN	1

2. Specification

2.1 Performance specifications

The performance specifications of the AJ65VBTCU-68DAVN are shown below. For general specifications, refer to detailed manual.

Item	AJ65VBTCU-68DAVN				
Protection class	IP1XB				
Digital input	16-bit signed binary (-4096 to +4095)				
Analog output	-10 to +10VDC (external load resistance: 2kΩ to 1MΩ)				
I/O characteristics, maximum resolution, accuracy (accuracy relative to maximum value of analog output value)	Digital Input Value	Analog Output Range	Accuracy		Max. Resolution
	-4000 to +4000	-10 to +10V	±0.3% (±30mV)	±0.2% (±20mV)	2.5mV
		User range setting 1 (-10 to +10V)			
	0 to 4000	0 to 5V	±0.3% (±15mV)	±0.2% (±10mV)	1.25mV
User range setting 2 (0 to 5V)		1.0mV			
Maximum conversion speed	1ms/channel				
Output short-circuit protection	Provided				
Absolute maximum output	±12V				
Number of analog output points	8 channels/module				
CC-Link station type	Remote device station (Ver.1 remote device station, Ver.2 remote device station)				
Number of occupied stations	When Ver.1 remote device station (Ver.1-compatible slave station) is set: 3 stations (RX/RV: 32 points each, RWr/RWw: 12 points each) When Ver.2 remote device station (Ver.2-compatible slave station) is set: 1 station (RX/RV: 32 points each, RWr/RWw: 16 points each)				
Communication cable	Ver.1.10 compatible CC-Link dedicated cable: FANC-110SBH, FA-CBL200PSBH, CS-110				


Item		AJ65VBTCU-68DAVN			
Isolation specifications		Specific isolated area	Isolation method	Dielectric withstand voltage	Insulation resistance
		Across communication system terminals and all analog input terminals	Photocoupler isolation	500V AC for 1 minute	5MΩ or higher, measured with 500V DC insulation resistance tester
		Across power supply system terminals and all analog input terminals	Transformer isolation		
		Between channels	Not isolated	-	-
Noise durability		By noise simulator of 500Vp-p noise voltage, 1μs noise width and 25 to 60Hz noise frequency			
External wiring system		<p>One-touch connector for communication [Transmission circuit] (5 pins pressure welding type, the plug for the connector is sold separately)</p> <p>One-touch connector for power supply and FG [Unit power supply and FG] (5 pins pressure welding type, the plug for the connector is sold separately)</p> <p>One-touch connector for analog I/O (4 pins pressure welding type, the plug for the connector is sold separately)</p> <p><Sold separately></p> <p>Online connector for communication : A6CON-LJ5P</p> <p>Online connector for power supply : A6CON-PWJ5P</p>			
Applicable wire size	One-touch connector for communication	Communication line : Ver. 1.10 compatible CC-Link dedicated cable 0.5mm ² (AWG#20) [φ2.2 to 3.0], shielded wire 0.5mm ² (AWG#20)			
	One-touch connector for power supply/FG	0.66 to 0.98 mm ² (AWG#18) [φ2.2 to 3.0] Wire diameter 0.16 mm or more			
	One-touch connector for analog I/O	φ1.0 to 1.4 (A6CON-P214), φ1.4 to 2.0 (A6CON-P220) [Applicable cable : 0.14 to 0.2 mm ²] φ1.0 to 1.4 (A6CON-P514), φ1.4 to 2.0 (A6CON-P520) [Applicable cable : 0.3 to 0.5 mm ²]			
Applicable DIN rail		TH35-7.5Fe, TH35-7.5Al (conforming to JIS C 2812) CC-Link connector type metal installation fitting : A6PLT-J65V1			
External supply power		24V DC (20.4V DC to 26.4V DC, ripple factor within 5%) Inrush current : 4.3A, within 1.2ms Current consumption 0.15A			
Weight		0.16kg			

Point	D/A conversion values are fluctuated by self-heating within approx. 30 minutes after power is turned ON.
-------	--

3. Names and Setting of Parts



The name of each part in the AJ65VBTCU-68DAVN is shown.

[Pin layout and signals name]



Pin arrangement	Pin No.	Signal name
<p>A module view from the top</p>	CONA,B	1 DA
		2 DB
		3 DG
		4 NC
		5 SLD
	CON1	1 CH1 V+
		2 NC
		3 CH1 COM
		4 NC
	CON2	1 CH2 V+
		2 NC
		3 CH2 COM
		4 NC
	CON3	1 CH3 V+
		2 NC
		3 CH3 COM
		4 NC
	CON4	1 CH4 V+
		2 NC
		3 CH4 COM
	4 NC	
CON5	1 CH5 V+	
	2 NC	
	3 CH5 COM	
	4 NC	
CON6	1 CH6 V+	
	2 NC	
	3 CH6 COM	
	4 NC	
CON7	1 CH7 V+	
	2 NC	
	3 CH7 COM	
	4 NC	
CON8	1 CH8 V+	
	2 NC	
	3 CH8 COM	
	4 NC	
CONC,D	1 FG	
	2 +24V (UNIT)	
	3 24G(UNIT)	
	4 NC	
	5 NC	

No.	Name and appearance	Description					
1)	Operation status display LED	POWER	ON : Power supply on OFF : Power supply off				
		RUN	<table border="0"> <tr> <td data-bbox="644 224 746 707">Normal mode</td> <td data-bbox="746 224 1516 707"> On : Normal operation Flickering: 0.1s intervals: Output range setting error, mode select switch setting error. This module is used as the Ver.2 remote device station (Ver.2 compatible slave station) when the network parameter mode is set to remote network Ver.1 mode. 0.5s intervals: Average value setting (count) time error. Mode select switch setting is changed after power-on. Off : 24VDC power supply shutoff or watchdog timer error occurred. </td> </tr> <tr> <td data-bbox="644 707 746 967">Test mode</td> <td data-bbox="746 707 1516 967"> On : Indicate that the SELECT/SET switch is in the SET position. Flickering: 0.1s intervals: Mode select switch setting error 0.5s intervals: An attempt was made to make setting outside the setting range at the time of offset/gain setting. Off : Indicates that the SELECT/SET switch is in the SELECT or center position. </td> </tr> </table>	Normal mode	On : Normal operation Flickering: 0.1s intervals: Output range setting error, mode select switch setting error. This module is used as the Ver.2 remote device station (Ver.2 compatible slave station) when the network parameter mode is set to remote network Ver.1 mode. 0.5s intervals: Average value setting (count) time error. Mode select switch setting is changed after power-on. Off : 24VDC power supply shutoff or watchdog timer error occurred.	Test mode	On : Indicate that the SELECT/SET switch is in the SET position. Flickering: 0.1s intervals: Mode select switch setting error 0.5s intervals: An attempt was made to make setting outside the setting range at the time of offset/gain setting. Off : Indicates that the SELECT/SET switch is in the SELECT or center position.
		Normal mode	On : Normal operation Flickering: 0.1s intervals: Output range setting error, mode select switch setting error. This module is used as the Ver.2 remote device station (Ver.2 compatible slave station) when the network parameter mode is set to remote network Ver.1 mode. 0.5s intervals: Average value setting (count) time error. Mode select switch setting is changed after power-on. Off : 24VDC power supply shutoff or watchdog timer error occurred.				
		Test mode	On : Indicate that the SELECT/SET switch is in the SET position. Flickering: 0.1s intervals: Mode select switch setting error 0.5s intervals: An attempt was made to make setting outside the setting range at the time of offset/gain setting. Off : Indicates that the SELECT/SET switch is in the SELECT or center position.				
		L RUN	On : Normal communication Off : Communication cutoff (time expiration error)				
L ERR.	On : Indicates that transmission speed setting or station number setting is outside the range. Flicker at fixed intervals : Indicates that transmission speed setting or station number setting was changed from that at power-on. Flicker at unfixed intervals: Indicates that you forgot fitting the termination resistor or the module or CC-Link dedicated cable is affected by noise. Off : Indicates normal communications.						
2)	Offset/gain adjusting LEDs	TEST CH <input type="checkbox"/>	Normal mode Normally OFF.				
		OFFSET GAIN	Test mode TEST : ON The OFFSET/GAIN/ CH <input type="checkbox"/> LEDs lit change every time the SELECT/SET switch is moved to SELECT.				
3)	SELECT/SET switch	The switch to be used for making the offset/gain settings during test mode.					
4)	UP/DOWN switch	Used to adjust the offset value and gain value of the channel specified by the SELECT/SET switch.					
5)	Mode select switch (Factory-set to "0")	The switch to be used for selecting the mode among Ver. <input type="checkbox"/> remote device station (Ver. <input type="checkbox"/> -compatible slave station)/Normal mode/Test mode					
		AJ65VBTCU-68DAVN					
		Ver.1 remote device station (Ver.1-compatible slave station)	0: Normal mode 1: Test mode (User range setting 1) 2: Test mode (User range setting 2)				
		Ver.2 remote device station (Ver.2-compatible slave station)	3: Normal mode 4: Test mode (User range setting 1) 5: Test mode (User range setting 2)				
-		6 to 7: Use prohibited					

No.	Name and appearance	Description																																																																																																														
6)	Transmission speed setting switches 	<table border="1" data-bbox="392 170 1382 427"> <thead> <tr> <th rowspan="2">Set Value</th> <th colspan="3">Setting Switches</th> <th rowspan="2">Transmission Speed</th> </tr> <tr> <th>4</th> <th>2</th> <th>1</th> </tr> </thead> <tbody> <tr> <td>0</td> <td>OFF</td> <td>OFF</td> <td>OFF</td> <td>156kbps</td> </tr> <tr> <td>1</td> <td>OFF</td> <td>OFF</td> <td>ON</td> <td>625kbps</td> </tr> <tr> <td>2</td> <td>OFF</td> <td>ON</td> <td>OFF</td> <td>2.5Mbps</td> </tr> <tr> <td>3</td> <td>OFF</td> <td>ON</td> <td>ON</td> <td>5.0Mbps</td> </tr> <tr> <td>4</td> <td>ON</td> <td>OFF</td> <td>OFF</td> <td>10Mbps</td> </tr> </tbody> </table> <p>Always set the transmission speed within the above range. The switches are all factory-set to OFF. Making any other setting than the above will result in an error flickering the "L ERR." LED. Confirm the transmission speed setting switch numbers on the seal located on the side face of the connector for analog I/O.</p>	Set Value	Setting Switches			Transmission Speed	4	2	1	0	OFF	OFF	OFF	156kbps	1	OFF	OFF	ON	625kbps	2	OFF	ON	OFF	2.5Mbps	3	OFF	ON	ON	5.0Mbps	4	ON	OFF	OFF	10Mbps																																																																													
Set Value	Setting Switches			Transmission Speed																																																																																																												
	4	2	1																																																																																																													
0	OFF	OFF	OFF	156kbps																																																																																																												
1	OFF	OFF	ON	625kbps																																																																																																												
2	OFF	ON	OFF	2.5Mbps																																																																																																												
3	OFF	ON	ON	5.0Mbps																																																																																																												
4	ON	OFF	OFF	10Mbps																																																																																																												
7)	Station number setting switches 	<p>Use the switches in STATION NO. "10", "20" and "40" to set the tens of the station number. Use the switches in STATION NO. "1", "2", "4" and "8" to set the units of the station number. The switches are all factory-set to OFF. Always set the station number within the range 1 to 64. You cannot set the same station number to two or more stations. Setting any other number than 1 to 64 will result in an error, flickering the "L ERR." LED.</p> <table border="1" data-bbox="392 936 1374 1339"> <thead> <tr> <th rowspan="2">Station Number</th> <th colspan="3">Tens</th> <th colspan="4">Units</th> </tr> <tr> <th>40</th> <th>20</th> <th>10</th> <th>8</th> <th>4</th> <th>2</th> <th>1</th> </tr> </thead> <tbody> <tr> <td>1</td> <td>OFF</td> <td>OFF</td> <td>OFF</td> <td>OFF</td> <td>OFF</td> <td>OFF</td> <td>ON</td> </tr> <tr> <td>2</td> <td>OFF</td> <td>OFF</td> <td>OFF</td> <td>OFF</td> <td>OFF</td> <td>ON</td> <td>OFF</td> </tr> <tr> <td>3</td> <td>OFF</td> <td>OFF</td> <td>OFF</td> <td>OFF</td> <td>OFF</td> <td>ON</td> <td>ON</td> </tr> <tr> <td>4</td> <td>OFF</td> <td>OFF</td> <td>OFF</td> <td>OFF</td> <td>ON</td> <td>OFF</td> <td>OFF</td> </tr> <tr> <td>:</td> <td>:</td> <td>:</td> <td>:</td> <td>:</td> <td>:</td> <td>:</td> <td>:</td> </tr> <tr> <td>10</td> <td>OFF</td> <td>OFF</td> <td>ON</td> <td>OFF</td> <td>OFF</td> <td>OFF</td> <td>OFF</td> </tr> <tr> <td>11</td> <td>OFF</td> <td>OFF</td> <td>ON</td> <td>OFF</td> <td>OFF</td> <td>OFF</td> <td>ON</td> </tr> <tr> <td>:</td> <td>:</td> <td>:</td> <td>:</td> <td>:</td> <td>:</td> <td>:</td> <td>:</td> </tr> <tr> <td>64</td> <td>ON</td> <td>ON</td> <td>OFF</td> <td>OFF</td> <td>ON</td> <td>OFF</td> <td>OFF</td> </tr> </tbody> </table> <p>(Example) To set the station number to "32", set the switches as indicated below.</p> <table border="1" data-bbox="392 1391 1374 1503"> <thead> <tr> <th rowspan="2">Station Number</th> <th colspan="3">Tens</th> <th colspan="4">Units</th> </tr> <tr> <th>40</th> <th>20</th> <th>10</th> <th>8</th> <th>4</th> <th>2</th> <th>1</th> </tr> </thead> <tbody> <tr> <td>32</td> <td>OFF</td> <td>ON</td> <td>ON</td> <td>OFF</td> <td>OFF</td> <td>ON</td> <td>OFF</td> </tr> </tbody> </table> <p>Confirm the station number setting switch numbers on the seal located on the side face of the connector for analog I/O.</p>	Station Number	Tens			Units				40	20	10	8	4	2	1	1	OFF	OFF	OFF	OFF	OFF	OFF	ON	2	OFF	OFF	OFF	OFF	OFF	ON	OFF	3	OFF	OFF	OFF	OFF	OFF	ON	ON	4	OFF	OFF	OFF	OFF	ON	OFF	OFF	:	:	:	:	:	:	:	:	10	OFF	OFF	ON	OFF	OFF	OFF	OFF	11	OFF	OFF	ON	OFF	OFF	OFF	ON	:	:	:	:	:	:	:	:	64	ON	ON	OFF	OFF	ON	OFF	OFF	Station Number	Tens			Units				40	20	10	8	4	2	1	32	OFF	ON	ON	OFF	OFF	ON	OFF
Station Number	Tens			Units																																																																																																												
	40	20	10	8	4	2	1																																																																																																									
1	OFF	OFF	OFF	OFF	OFF	OFF	ON																																																																																																									
2	OFF	OFF	OFF	OFF	OFF	ON	OFF																																																																																																									
3	OFF	OFF	OFF	OFF	OFF	ON	ON																																																																																																									
4	OFF	OFF	OFF	OFF	ON	OFF	OFF																																																																																																									
:	:	:	:	:	:	:	:																																																																																																									
10	OFF	OFF	ON	OFF	OFF	OFF	OFF																																																																																																									
11	OFF	OFF	ON	OFF	OFF	OFF	ON																																																																																																									
:	:	:	:	:	:	:	:																																																																																																									
64	ON	ON	OFF	OFF	ON	OFF	OFF																																																																																																									
Station Number	Tens			Units																																																																																																												
	40	20	10	8	4	2	1																																																																																																									
32	OFF	ON	ON	OFF	OFF	ON	OFF																																																																																																									
8)	One-touch connector for communication	A one-touch connector for connection of the communication line When carrying out wiring, connect two optional one-touch connector plugs for communication at top and bottom.																																																																																																														
9)	One-touch connector for power supply and FG	A one-touch connector for connection of the module power supply line and FG When carrying out jumper wiring, connect two optional one-touch connector plugs for power supply/FG at top and bottom.																																																																																																														
10)	One-touch connector for analog I/O	One-touch connector for analog I/O Connect a one-touch connector plug when wiring.																																																																																																														
11)	DIN rail hook	Used to mount the module to the DIN rail.																																																																																																														

Point

After power-on, do not change the mode select switch setting.
 If you change it midway during operation, the setting at power-on is valid.

4. Loading and Installation

4.1 Precautions when handling

The following is an explanation of handling precautions of the module.

- (1) Because the case of the module is made of resin, be careful not to drop it or expose it to strong impact.

4.2 Installation environment

Never install the module in the following environments:

- (1) Locations where the ambient temperature is outside the range of 0 to 55°C.
- (2) Locations where the ambient humidity is outside the range of 10 to 90%RH.
- (3) Locations where dew condensation takes place due to sudden temperature changes.
- (4) Locations where there are corrosive and/or combustible gasses.
- (5) Locations where there is a high level of conductive power (such as dust and iron filings, oil mist, salt, and organic solvents).
- (6) Locations exposed to the direct rays of the sun.
- (7) Locations where strong power and magnetic fields are generated.
- (8) Locations where vibration and shock are directly transmitted to the main module.

5. Data Link Cable Wiring


5.1 Instructions for handling the CC-Link dedicated cables

Do not handle the CC-Link dedicated cables roughly as described below. Doing so can damage the cables.


- Compact with a sharp object.
- Twist the cable excessively.
- Pull the cable hard. (more than the permitted elasticity.)
- Step on the cable.
- Place an object on the top.
- Scratch the cable's protective layer.

5.2 Connection of the CC-Link dedicated cables

Connect the CC-Link dedicated cable between the AJ65VBTCU-68DAVN and master module as shown below.




[Power supply/FG cable wiring diagram]



* The power cables cannot be connected with the other remote I/O module having the one-touch connector for power supply.

[CC-Link dedicated cable wiring diagram]



Ver.1.10 Compatible CC-Link dedicated cable (FANC-110SBH,CS-110,FA-CBL200PSBH)

Point

- On this unit, use the Ver. 1.10-compatible CC-Link dedicated cable (FANC-110SBH, CS-110, FA-CBL200PSBH). You cannot use the Ver. 1.10-compatible CC-Link dedicated cables of other than the above types, CC-Link dedicated cables and CC-Link dedicated, high-performance cables.
- The shield cable of the CC-Link dedicated cable should be connected to "SLD" in each module, and both ends should be grounded through "FG".

6. Wiring


6.1 Wiring precautions

To obtain maximum performance from the functions of AJ65VBTCU-68DAVN and improve the system reliability, an external wiring with high durability against noise is required.

The precautions when performing external wiring are as follows:

- (1) Use separate cables for the AC and AJ65VBTCU-68DAVN external input signals, in order not to be affected by the AC side surge or conductivity.
- (2) Do not bundle or place with load carrying wires other than the main circuit line, high voltage line or PLC. Noises, surges, or conductivity may affect the system.
- (3) Place a one-point grounding on the PLC side for the shielded line or shielded cable.

6.2 Module connection example



- *1 Use a two-core twist shielded line for the wiring.
- *2 If noise or ripples occur in the external wiring, connect a 0.1 to 0.47 μ F capacitor (25V or higher voltage-resistant product) to the input terminals of the external device.

Point







- Do not insert the one-touch connector plug for I/O of the one-touch connector type/connector type compact remote I/O unit into the one-touch connector for analog I/O accidentally. Doing so can cause the module to be damaged.

7. How to Wire the One-Touch Connector Plug

This section describes the way to wire the one-touch connector plug. Refer to the AJ65VBTCU-68DAVN Digital-Analog User's Manual for more information on the types and specifications of the one-touch connector plugs which conform to the AJ65VBTCU-68DAVN.

(1) Cable termination work

Do the following work on the cable terminations of the communication that are inserted into the one-touch connector plugs.


Communication Cable Termination Work	
<p>1. Cut the outer insulation layer.</p> 	<p>2. Separate the shield and drain wire and cut the shield.</p> 
<p>3. Cut the aluminum tape and intervening cord.</p> 	<p>4. Straighten out the drain wire and twist it from the root. (3cm seven or more times)</p> 
Termination work for analog output cable	
<p>1. Cut the outer insulation layer.</p> 	<p>2. Cut the ends of shielded wires to make them adequate in length.</p> 

Point

- Where possible, round the tip that was cut with nippers or like. If the section of the cable to be inserted is not round, the cable may be caught at any point and not go far enough.
- Do insulation work as necessary on the area of the shield that will not be inserted into the one-touch connector plug.

(2) Checking the plug cover

Check whether the plug cover is installed in the plug.




Caution:

Before inserting the cable, do not push the plug cover into the plug. Once insulation-displaced, the plug cannot be reused.

(3) Inserting the cable

Lift the back of the plug cover and insert the cable until it makes contact with the plug.






Insert the signal cables into the one-touch connector plug as shown below.

<For communication>

<For power supply/FG>

<For analog output>




Point

- Insert the cables far enough.
Not doing so can cause an insulation displacement fault.
- The cable inserted may come out of the cover front.
At this time, pull it back until the cable tip goes back into the plug cover.

(4) Insulation displacement of plug cover

Using pliers or like, push the plug cover into the plug to insulation-displace it.


After insulation displacement, make sure that the plug cover is securely installed in the plug as shown below.



Point

- The plug cover and plug latches may not engage at the time of insulation displacement, raising the cover. Since the plug cover has not been insulation-displaced sufficiently in this state, push the cover into the plug until it is installed securely.

8. External Dimension Diagram



*: This section should be 14.5mm (0.57inch) when an online connector is not installed.

Unit:mm(inch)

Warranty

Mitsubishi will not be held liable for damage caused by factors found not to be the cause of Mitsubishi; machine damage or lost profits caused by faults in the Mitsubishi products; damage, secondary damage, accident compensation caused by special factors unpredictable by Mitsubishi; damages to products other than Mitsubishi products; and to other duties.

⚠ For safe use

- This product has been manufactured as a general-purpose part for general industries, and has not been designed or manufactured to be incorporated in a device or system used in purposes related to human life.
- Before using the product for special purposes such as nuclear power, electric power, aerospace, medicine or passenger movement vehicles, consult with Mitsubishi.
- This product has been manufactured under strict quality control. However, when installing the product where major accidents or losses could occur if the product fails, install appropriate backup or failsafe functions in the system.

Country/Region	Sales office/Tel	Country/Region	Sales office/Tel
U.S.A	Mitsubishi Electric Automation Inc. 500 Corporate Woods Parkway Vernon Hills, IL 60061, U.S.A. Tel : +1-847-478-2100	Hong Kong	Mitsubishi Electric Automation (Hong Kong) Ltd. 10th Floor, Manulife Tower, 169 Electric Road, North Point, Hong Kong Tel : +852-2887-8870
Brazil	MELCO-TEC Rep. Com.e Assessoria Tecnica Ltda. Rua Correia Dias, 184, Edificio Paraiso Trade Center-8 andar Paraiso, Sao Paulo, SP Brazil Tel : +55-11-5908-8331	China	Mitsubishi Electric Automation (Shanghai) Ltd. 4/F Zhi Fu Plazz, No.80 Xin Chang Road, Shanghai 200003, China Tel : +86-21-6120-0808
Germany	Mitsubishi Electric Europe B.V. German Branch Gothaer Strasse 8 D-40880 Ratingen, GERMANY Tel : +49-2102-486-0	Taiwan	Setsuyo Enterprise Co., Ltd. 6F No.105 Wu-Kung 3rd.Rd, Wu-Ku Hsiang, Taipei Hsine, Taiwan Tel : +886-2-2299-2499
U.K	Mitsubishi Electric Europe B.V. UK Branch Travellers Lane, Hatfield, Hertfordshire., AL10 8XB, U.K. Tel : +44-1707-276100	Korea	Mitsubishi Electric Automation Korea Co., Ltd. 1480-6, Gayang-dong, Gangseo-ku Seoul 157-200, Korea Tel : +82-2-3660-9552
Italy	Mitsubishi Electric Europe B.V. Italian Branch Centro Dir. Colleoni, Pal. Perseo-Ingr.2 Via Paracelso 12, I-20041 Agrate Brianza., Milano, Italy Tel : +39-039-60531	Singapore	Mitsubishi Electric Asia Pte, Ltd. 307 Alexandra Road #05-01/02, Mitsubishi Electric Building, Singapore 159943 Tel : +65-6470-2460
Spain	Mitsubishi Electric Europe B.V. Spanish Branch Carretera de Rubi 76-80, E-08190 Sant Cugat del Valles, Barcelona, Spain Tel : +34-93-565-3131	Thailand	Mitsubishi Electric Automation (Thailand) Co., Ltd. Bang-Chan Industrial Estate No.111 Moo 4, Serithai Rd, T.Kannayao, A.Kannayao, Bangkok 10230 Thailand Tel : +66-2-517-1326
France	Mitsubishi Electric Europe B.V. French Branch 25, Boulevard des Bouvets, F-92741 Nanterre Cedex, France TEL: +33-1-5568-5568	Indonesia	P.T. Autoteknindo Sumber Makmur Muara Karang Selatan, Block A/Utara No.1 Kav. No.11 Kawasan Industri Pergudangan Jakarta - Utara 14440, P.O.Box 5045 Jakarta, 11050 Indonesia Tel : +62-21-6630833
South Africa	Circuit Breaker Industries Ltd. Private Bag 2016, ZA-1600 Isando, South Africa Tel : +27-11-928-2000	India	Messung Systems Pvt, Ltd. Electronic Sadan NO:III Unit No15, M.I.D.C Bhosari, Pune-411026, India Tel : +91-20-2712-3130
		Australia	Mitsubishi Electric Australia Pty. Ltd. 348 Victoria Road, Rydalmere, N.S.W 2116, Australia Tel : +61-2-9684-7777

MITSUBISHI ELECTRIC CORPORATION

HEAD OFFICE : TOKYO BUILDING, 2-7-3 MARUNOUCHI, CHIYODA-KU, TOKYO 100-8310, JAPAN
NAGOYA WORKS : 1-14, YADA-MINAMI 5-CHOME, HIGASHI-KU, NAGOYA, JAPAN

When exported from Japan, this manual does not require application to the Ministry of Economy, Trade and Industry for service transaction permission.

Specifications subject to change without notice.
Printed in Japan on recycled paper.