

mitsubishi

CC-Link System

Spring Clamp Terminal Block Type

Repeater Hub Module

User's Manual

AJ65BTS-RPH

Thank you for buying the Mitsubishi general-purpose programmable logic controller MELSEC-A series.

Prior to use, please read both this manual and related manuals thoroughly and familiarize yourself with the product.



MODEL	AJ65BTS-RPH-U
MODEL CODE	13JP97
IB(NA)-0800346-B(0612)MEE	

●SAFETY PRECAUTIONS●

(Read these precautions before using.)

When using Mitsubishi equipment, thoroughly read this manual and the associated manuals introduced in this manual. Also pay careful attention to safety and handle the module properly.

The precautions given in this manual are concerned with this product. Refer to the user's manual of the network system to use for a description of the network system safety precautions.

These SAFETY PRECAUTIONS classify the safety precautions into two categories: "DANGER" and "CAUTION".




DANGER

Indicates that incorrect handling may cause hazardous conditions, resulting in death or severe injury.



CAUTION

Indicates that incorrect handling may cause hazardous conditions, resulting in medium or slight personal injury or physical damage.

Depending on circumstances, procedures indicated by  **CAUTION** may also be linked to serious results.

In any case, it is important to follow the directions for usage.

Store this manual in a safe place so that you can take it out and read it whenever necessary. Always forward it to the end user.

[DESIGN PRECAUTIONS]



DANGER

- Input/output could be switched on or off when a problem occurs in the repeater module.
So build an external monitoring circuit that will monitor any input/output signals that could cause a serious accident.



CAUTION

- Use the module in an environment that meets the general specifications contained in this manual. Using this module in an environment outside the range of the general specifications could result in electric shock, fire, erroneous operation, and damage to or deterioration of the product.
- Do not install the control wires or communication cables together with the main circuit or power wires.
Keep a distance of 100mm (3.94inch) or more between them.
Not doing so could result in malfunctions due to noise.

[INSTALLATION PRECAUTIONS]



CAUTION

- Do not directly touch the module's conductive parts.
Doing so may cause malfunctions or failure of the module.
- Fix the module securely with a DIN rail or screws, and when using screws, tighten them within the specified torque range.
Undertightening can cause a drop, short circuit or malfunction. Overtightening can cause a drop, short circuit or malfunction due to damage to the screw or module.

[WIRING PRECAUTIONS]



DANGER

- Before installation or wiring, be sure to shut off all phases of the external power supply used in the system.
If the power is not disconnected at all phases an electric shock or product damage may result.



CAUTION

- Always earth the FG terminal to the protective earth conductor. Otherwise there will be an electric shock or misoperation.
- Perform correct wiring for the module according to the product's rated voltage and terminal arrangement. Connecting to a power supply different from rating or miss-wiring may cause fire and/or product failure.
- Ensure that no foreign matter such as chips and wire-offcuts enter the module. Foreign matter can cause a fire, failure or malfunction.
- Be sure that the communication cable connected to the module is kept in the duct or is fixed with cramps.
Failure to do so may cause a damage to the module or cables due to dangling, shifting or inadvertent handling of cable, or malfunction because of bad cable contacts.
- Do not install the control lines together with the communication cables, or bring them close to each other. Failure to do so may cause malfunctions due to noise.
- When disconnecting the communication and power supply cables from the module, do not hold and pull the cable part.
Disconnect the cables after loosening the screws in the portions connected to the module.
Pulling the cables connected to the module can damage the module and cables or can cause a malfunction due to a cable connection fault.

[STARTING AND MAINTENANCE PRECAUTIONS]



CAUTION

- Do not disassemble or modify the modules.
Doing so could cause failure, erroneous operation, injury, or fire.
- Be sure to shut down all the phases of the externally supplied power used in the system before cleaning the module, retightening the module fixing screws, and attaching/removing the module.
Not doing so can cause the module to fail or malfunction.
- Do not install/remove the terminal block more than 50 times after the first use of the product. (IEC 61131-2 compliant)
- Before handling the module, make sure to touch a grounded metal object to discharge the static electricity from the human body.
Failure to do so may cause a failure or malfunctions of the module.

[DISPOSAL PRECAUTIONS]



CAUTION

- When disposing of this product, treat it as industrial waste.

REVISIONS

* The manual number is given on the bottom right of the cover.

Print Date	*Manual Number	Revision
Oct., 2006	IB(NA)-0800346-A	First edition
Dec., 2006	IB(NA)-0800346-B	<div>Correction</div> SAFETY PRECAUTIONS, About the Manual, Section 2.2, 2.3, 3.1, 3.2, 4.2.1

This manual confers no industrial property rights or any rights of any other kind, nor does it confer any patent licenses. Mitsubishi Electric Corporation cannot be held responsible for any problems involving industrial property rights which may occur as a result of using the contents noted in this manual.

CONTENTS

1. OVERVIEW	1
1.1 Features	1
2. SYSTEM CONFIGURATION	3
2.1 Total configuration	3
2.2 Applicable system	4
2.3 Cautions on system configuration	5
3. SPECIFICATION	12
3.1 General specifications	12
3.2 Performance specifications	14
3.3 Specifications of connection cable	17
3.4 Maximum transmission distance	18
4. PROCEDURE UP TO START OF DATA LINK	19
4.1 Procedure up to start of data link	19
4.2 Mounting and installation	20
4.2.1 Cautions on handling	20
4.2.2 Installation environment	25
4.3 Names and settings of parts	26
4.4 Connection of module through CC-Link dedicated cable	30
4.5 Check for state of connection (line test)	31
5. TROUBLESHOOTING	34
6. EXTERNAL DIMENSIONS	38

About the Manuals

The following manuals are also related to this product.
Order them if necessary.

Related Manual

Manual name	Manual No. (Model code)
CC-Link System Master/Local Module Type AJ61BT11/ A1SJ61BT11 User's Manual	IB-66721 (13J872)
CC-Link System Master/Local Module Type AJ61QBT11/ A1SJ61QBT11 User's Manual	IB-66722 (13J873)
CC-Link System Master/Local Module User's Manual QJ61BT11N	SH-080394E (13JR64)
CC-Link System Repeater (T-junction) Module Type AJ65SBT-RPT User's Manual	IB-0800078 (13JQ81)
CC-Link System Optical Repeater Module Type AJ65SBT- RPS/AJ65SBT-RPG User's Manual	IB-0800089 (13JQ85)
CC-Link System Space Optical Repeater Module Type AJ65BT-RPI-10A/AJ65BT-RPI-10B User's Manual	IB-0800090 (13JQ86)
CC-Link System Low Profile Waterproof Type Repeater Hub Module User's Manual	IB-0800288 (13JP55)

Compliance with the EMC and Low Voltage Directives

When incorporating the Mitsubishi PLC into other machinery or equipment and keeping compliance with the EMC and low voltage directives, refer to Chapter 3, "EMC Directives and Low Voltage Directives" of the User's Manual (Hardware) included with the CPU module or base unit used.

The CE logo is printed on the rating plate of the PLC, indicating compliance with the EMC and low voltage directives.

To conform this product to the EMC Directive and Low Voltage Directive, refer to the Section of "CC-Link Modules" in Chapter 3 "EMC Directive and Low Voltage Directive" of the User's Manual (Hardware) of the CPU module used.

Abbreviated names, generic names and terms

Abbreviated names, generic names and terms	Description
AJ-65BTS-RPH	Abbreviation of AJ65BTS-RPH type CC-Link system spring clamp terminal Block type Repeater hub module.
AJ65FBTA-RPH	Abbreviation of AJ65FBTA-RPH type CC-Link system low profile waterproof type repeater hub module.
AJ65SBT-RPT	Abbreviation of AJ65SBT-RPT type CC-Link system repeater (T-junction) module.
AJ65SBT-RPS/RPG	Abbreviation of AJ65SBT-RPS/AJ65SBT-RPG type CC-Link system optical repeater module.
AJ65BT-RPI-10A/10B	Abbreviation of AJ65BT-RPI-10A/AJ65BT-RPI-10B type CC-Link system space optical repeater module.
AJ65SBT-CLB	Abbreviation of AJ65SBT-CLB CC-Link - CC-Link/LT bridge module.
Segment	System between terminating resistors connected to each other through cross-over cables. The conventional CC-Link system can be said to be configured with one segment.
Master station	Station to control the data link system. One station is required for each system.
Local station	Station which has a sequencer CPU and can communicate with the master station and the other local stations.
Remote I/O station	Remote station processing only information in unit of bit. (AJ65BTB1-16D, AJ65SBTB1-16D, etc.)
Remote device station	Remote station processing only information in unit of bit and in unit of word. (AJ65BT-64AD, AJ65BT-64DAV, AJ65BT-64DAI, etc.)
Remote station	Generic name of remote I/O station and remote device station. Controlled by the master station.
Intelligent device station	Station allowing transient transmission such as AJ65BT-R2. (Including local stations)
Repeater	Module for expanding the CC-Link system by connecting the segments to each other.
Standby master station	Backup station which inherits data link control when the master station comes off parallel due to error.
Slave station	Generic term of remote I/O station, remote device station, local station, intelligent device station, and standby master station.
Master local module	Generic name of QJ61BT11N, QJ61BT11, AJ61BT11, A1SJ61BT11, AJ61QBT11 and A1SJ61QBT11.

Abbreviated names, generic names and terms	Description
Master module	Generic name of QJ61BT11N, QJ61BT11, AJ61BT11, A1SJ61BT11, AJ61QBT11 and A1SJ61QBT11 when these are used as the master station.
Local module	Generic name of QJ61BT11N, QJ61BT11, AJ61BT11, A1SJ61BT11, AJ61QBT11 and A1SJ61QBT11 when these are used as the local station.
Intelligent device module	Module allowing transient transmission such as AJ65BT-R2.

Product structure

The product structure of AJ65BTS-RPH is as shown below.

Product name	Quantity
AJ65FBTA-RPH module	1
Terminating resistor kit	1
For a trunk line (Bar terminal type): 110Ω (brown, brown, brown)	1
For a trunk line (Bar terminal type): 130Ω (brown, orange, brown)	1
For a branch line (Y terminal type): 110Ω (brown, brown, brown)	8

1. OVERVIEW

This User's Manual describes the specifications, names of parts, and settings of the AJ65BTS-RPH type CC-Link system spring clamp terminal block type repeater hub module (hereafter abbreviated as AJ65BTS-RPH) used in the CC-Link system.


1.1 Features

The AJ65BTS-RPH is the module designed for improving flexibility in cable wiring of the CC-Link system.

Using the AJ65BTS-RPH allows the extension of the transmission distance and star-topology wiring (with 8 branch lines) in the CC-Link system.

- (1) Star-topology wiring (T-branch) with 8 branch lines (segments) available in CC-Link system


By placing the AJ65BTS-RPH between modules of the CC-Link system, star-topology wiring (T-branch) with up to 8 branch lines (segments) can be used in the CC-Link system of all transmission rates (10Mbps, 5Mbps, 2.5Mbps, 625kbps, and 156kbps).



(2) Extended transmission distance in CC-Link system

Use of AJ65BTS-RPH enables the transmission distance of the CC-Link system to be extended.

In addition, use of multiple modules enables the transmission distance of the CC-Link system to be extended up to 2 stages.



*1 Max. transmission distance at a transmission speed of 156kbps.

*2 Though it is not shown here, the other remote stations can be connected between the repeaters.

(3) Energy saving realized by adoption of a spring clamp terminal block

(a) The AJ65BTS-RPH has adopted a spring clamp terminal block. Because screw tightening is not needed, working steps can be reduced.

(b) The terminal block can be installed to or removed from the module, which reduces the maintenance cost and improves the maintainability.

(c) All the operation and wiring parts are placed on the module front, allowing easier operation and wiring.

(4) Improved maintainability by system separation

By using the AJ65BTS-RPH, any of the systems can be separated and error location can be identified quickly.


This prevents the whole system from being seriously affected by an error.

POINT
Branch lines with no error can send/receive data normally, not influenced by each other.

2. SYSTEM CONFIGURATION

2.1 Total configuration

The total configuration employed when the AJ65BTS-RPH is used is as shown below.



*1 The transmission speed of each segment must be matched with that of the master station.

*2 2 stages of segments max. are allowed to be used.

*3 The 130Ω terminating resistor is not usable for a segment connected on the branch line side of the AJ65BTS-RPH.

Use the 110Ω terminating resistor that is included with the AJ65BTS-RPH.

2.2 Applicable system

This section describes usable modules and cables.

(1) Modules connectable on the branch line side

The types of the modules connectable on the branch line side of the AJ65BTS-RPH are shown below.

Table 2.1 Modules connectable on the branch line side

Category	Module types
Slave station	Remote I/O station
	Remote device station
	Intelligent device station
	Local station
Repeater	AJ65BTS-RPH
	AJ65FBTA-RPH
	AJ65SBT-RPT
	AJ65SBT-RPS/RPG
	AJ65BT-RPI-10A/10B
Bridge	AJ65SBT-CLB

(2) Applicable communication cables

The communication cables connectable to the AJ65BTS-RPH are shown below.

Table 2.2 Applicable communication cables

Connector name	Applicable cable		Terminal resistance
	CC-Link version	Name	
Trunk line side	Ver.1.00	CC-Link dedicated high-performance cable	130Ω
		CC-Link dedicated cable	110Ω
Branch line side	Ver.1.10	CC-Link dedicated cable	
	Ver.1.00	CC-Link dedicated cable	
	Ver.1.10	CC-Link dedicated cable	

POINT

The master station and stand by master station can not be connected to the branch line side.


2.3 Cautions on system configuration

(1) Conditions of usable master module


When the AJ61BT11, A1SJ61BT11, AJ61QBT11 and A1SJ61QBT11 modules are used, those of the functional version B or later must be employed. Use the master module bearing the version 9707 B or later in the DATE column of the name plate as shown in the figure below.

When the QJ61BT11N, QJ61BT11 module are used, any module can be used irrespective of the version.

(a) Rating plate of AJ61BT11 or AJ61QBT11




(b) Rating plate of A1SJ61BT11 or A1SJ61QBT11



- (2) Max. number of modules connected to configure CC-Link system
Up to 64 modules of repeaters can be connected in one segment.
In the CC-Link system where repeaters are used, also the number of remote stations capable of being controlled by one master station is the same as in the other systems.

For details, refer to the User's Manual of the applicable master module.

- (3) Max. number of stages connected to configure segment
Use of AJ65BTS-RPH enables communication between the master station located in a segment and a remote station located in a segment apart by 2 stages max. from the segment where the master station exists.




- (4) Instructions for using different models of repeaters in combination
 Note that when combining the repeaters of different models, there are the following restrictions on the number of connectable repeaters and the number of connected stages.

Table 2.3 Max. number of repeaters when using different models


Combination pattern	Max. number of repeaters						Max. number of stages
	AJ65BTS-RPH	AJ65FBTA-RPH	AJ65SBT-RPT	AJ65SBT-RPS	AJ65SBT-RPG	AJ65BT-RPI-10A/10B	
1)	1	—	2	—	—	—	3
	—	1	2	—	—	—	
2)	1	—	—	2(1set)	-	—	2
	1	—	—	—	2(1set)	—	
	—	1	—	2(1set)	—	—	
	—	1	—	—	2(1set)	—	
3)	1	—	—	—	—	2(1set)	2
	—	1	—	—	—	2(1set)	
4)	—	—	2	4(2set)	—	—	4
5)	—	—	2	—	2(1set)	—	3
6)	—	—	2	—	—	2(1set)	
7)	—	—	—	2(1set)	2(1set)	—	2
8)	—	—	—	2(1set)	—	2(1set)	
	—	—	—	—	2(1set)	2(1set)	
9)	1	1	—	—	—	—	

POINT


- For the CC-Link system, up to 2 repeater types can be used in combination.
Using 3 models or more is not allowed.
- When repeaters are connected in the same segment by link wiring, up to 64 modules can be connected.
For details, refer to the user's manual of the master module used.
- Ex.) A CC-Link system with combination pattern 3) is built




(a) Combination pattern 1)




(b) Combination pattern 2)




(c) Combination pattern 3)




(d) Combination pattern 4)




(e) Combination pattern 5)




(g) Combination pattern 7)




(f) Combination pattern 6)



(h) Combination pattern 8)



(i) Combination pattern 9)



3. SPECIFICATION

3.1 General specifications

The General specifications of the AJ65BTS-RPH are shown below.

Table 3.1 General specifications

Item	Specifications					
Operating ambient temperature	0 to 55°C					
Storage ambient temperature	-20 to 75°C					
Operating ambient humidity	10 to 90%RH, non-condensing					
Storage ambient humidity	10 to 90%RH, non-condensing					
Vibration resistance	Conforming to JIS B 3502, IEC 61131-2		Frequency	Acceleration	Amplitude	Sweep count
		Under intermittent vibration	10 to 57Hz	—	0.075mm (0.003inch)	10 times each in X, Y, Z directions (for 80min.)
			57 to 150Hz	9.8m/s ²	—	
		Under continuous vibration	10 to 57Hz	—	0.035mm (0.001inch)	
			57 to 150Hz	4.9m/s ²	—	
Shock resistance	Conforming to JIS B 3502, IEC 61131-2 (147m/s ² , 3 times in each of 3 directions X, Y, Z)					
Operating ambience	No corrosive gases					
Operating altitude*3	2000m (6562ft.) max.					
Installation location	On the control panel*4					
Overvoltage category*1	II max.					
Pollution level*2	2 max.					

- *1 Indicates the location where the device is connected from the public cable network to the device structure wiring area.
Category II applies to the devices to which the power is supplied from a fixed equipment. Surge withstand voltage for devices with up to 300V of rated voltage is 2500V.
- *2 This is an index which indicates the degree of conductive object generation in the environment Pollution level 2 is when only non-conductive pollution occurs.
A temporary conductivity caused by condensation must be expected occasionally.
- *3 Do not use or store the PLC in the environment where the pressure is higher than the atmospheric pressure at sea level.
Otherwise, malfunction may result. To use the PLC in a high-pressure environment, contact your local Mitsubishi representative.
- *4 It can also be installed to any other than a control panel if the conditions such as operating ambient temperature and humidity are satisfied.

3.2 Performance specifications

The performance specifications of the AJ65BTS-RPH module are shown below.

Table 3.2 Performance specifications (1/2)

Item	Specifications	
Station number	— (none)	
CC-Link station type	— (none)	
Number of occupied stations	0 (none)	
Transmission rate	Can select from 156kbps / 625kbps / 2.5Mbps / 5Mbps / 10Mbps	
No. of connectable slave stations	The total number of modules connected to a trunk line and branch line shall conform to the maximum number of connectable modules of the master module used. For details, refer to the user's manual of the master modules used.	
Max. No. of modules connected to the trunk line	64 (Refer to Section 2.3(2))	
Connection position	Trunk line side	No restriction (compliant with the CC-Link specifications)
	Branch line side	Connect to the end of the branch line (segment end)
Max. number of stages connected to configure segment	AJ65BTS-RPH only (Refer to Section 2.3(3))	2nd stage
	Combination of AJ65BTS-RPH and AJ65SBT-RPT (Refer to Section 2.3 (4))	3rd stage
	Combination of AJ65BTS-RPH and one of AJ65FBTA-RPH, AJ65SBT-RPS/RPG, or AJ65BT-RPI (Refer to Section 2.3 (4))	2nd stage
Max. transmission distance of each segment	Varies according to transmission rate (Refer to Section 3.4.).	
Terminating resistor	Trunk line side	110Ω, or 130Ω can be selected.
	Branch line side	110Ω (built-in)
Terminal block	Spring clamp terminal block	
Applicable cable size	AWG #24 to 12, φ0.5 to 1.78mm single cable, 0.2 to 2.5mm ² stranded cable	
Applicable solderless terminal	Refer to table 3.3	

Table 3.2 Performance specifications (2/2)

Item		Specifications
Mounting orientation		No restriction (mountable in six orientations)
Module installation screw		M4 mounting screw
Power supply	Voltage	24V DC external power supply (20.4 to 26.4V, ripple within $\pm 5\%$)
	Current	0.36A (TYP. 24V DC)
Noise durability		Simulator noise of 500 Vp-p, obtained by a noise simulator using noise width of 1μ s and noise frequency of 25 to 60 Hz
Maximum voltage		500V AC for 1 minute between all DC external terminals and ground
Insulation resistance		10M Ω or higher, measured with a 500V DC insulation resistance tester
Protection of degree		IP2X
External dimensions		197.4mm (7.77in.) (W) \times 65mm (2.56in.) (H) \times 65.8mm (2.59in.) (D)
Weight		0.37kg

Table 3.3 Applicable solderless terminals (bar terminals) and crimp tools

Product name	Model name	Maker	Remark
Bar-type solderless terminal	FA-TVC125T9	Mitsubishi Electric Engineering Co., Ltd.	For CC-Link dedicated cables (0.3 to 1.65mm ²)
Tool for bar-type solderless terminals	FA-NH65A		
Bar-type solderless terminal	TE0.5-10	NICHIFU TERMINAL MFG. Co., Ltd.	For CC-Link dedicated cables (0.3 to 0.5mm ²)
	TE0.75-10		For power supply cables (0.75mm ²)
	TE1.0-10		For power supply cables (1.0mm ²)
	TE1.5-10		For power supply cables (1.5mm ²)
	TE2.5-12		For power supply cables (2.5mm ²)* ²
Tool for bar-type solderless terminals	NH-79		
Bar-type solderless terminal	AI0.5-10WH	PHOENIX CONTACT	For CC-Link dedicated cables (0.5mm ²)
	AI0.75-10GY		For power supply cables (0.75mm ²)
	AI1-10RD		For power supply cables (1.0mm ²)
	AI1.5-10BK		For power supply cables (1.5mm ²)
	AI2.5-10BU		For power supply cables (2.5mm ²)* ²
Tool for bar-type solderless terminals	CRIMPFOX UD6		
	CRIMPFOX UD6-4		*1
	CRIMPFOX UD6-6		*1
	CRIMPFOX ZA3		

*1: When shielding wires, power supply cables of 2 mm² (AWG #14) or FG wires are crimped to bar terminals using the CRIMPFOX UD6-4 or CRIMPFOX UD6-6, bar terminals may not be able to connect to the terminal block depending on the cross-sectional shape after crimping.

*2: When power supply cables of 2 mm² (maximum size of applicable cables) or FG wires are crimped to bar terminals of 2.5 mm², bar terminals may not be able to connect to the terminal block.

3.3 Specifications of connection cable

Use the CC-Link dedicated cable for the CC-Link system. If a cable other than the CC-Link dedicated cable is used, the performance of the CC-Link system cannot be guaranteed.

For the CC-Link cable specifications and any other inquiries, refer to the following:

CC-Link Partner Association website: <http://www.cc-link.org/>

REMARK

For details, refer to the CC-Link cable wiring manual issued by the CC-Link Partner Association.

3.4 Maximum transmission distance

The maximum transmission distance varies depending on the set-up of transmission rate and the number of connected segments (stages).





Table 3.4 Conditions for change in maximum transmission distance

Condition	Description
Transmission rate	Maximum transmission distance in each segment is the same as that of the normal CC-Link system (the system with one segment only). It varies depending on the transmission rate. For details, refer to the user's manual of the master module used. (The station-to-station cable length for the repeater is the same as that for the remote I/O station.)
No. of stages for segment connection	Maximum transmission distance for one segment is added for each additional stage connection.

4. PROCEDURE UP TO START OF DATA LINK

4.1 Procedure up to start of data link

The procedure ranging from the installation of the AJ65BTS-RPH module to the start of data link is described below.



POINT

The procedure described here is for the AJ65BTS-RPH module only. In order for you to understand the procedure of the entire CC-Link system, refer to the User's Manual of the applicable master module.

4.2 Mounting and installation

4.2.1 Cautions on handling

Cautions on handling the AJ65BTS-RPH module are described below.



DANGER

- Before installation or wiring, be sure to shut off all phases of the external power supply used in the system. If the power is not disconnected at all phases an electric shock or product damage may result.



CAUTION

- Do not install the control wires or communication cables together with the main circuit or power wires. Keep a distance of 100mm (3.94inch) or more between them. Not doing so could result in malfunctions due to noise.
- Do not directly touch the module's conductive parts or electronic components. Doing so may cause malfunctions or failure of the module.
- Fix the module securely with screws. Tighten the screws securely within the specified torque range.
Undertightening can cause a drop, short circuit or malfunction. Overtightening can cause a drop, short circuit or malfunction due to damage to the screw or module.
- Always earth the FG terminal to the protective earth conductor. Otherwise there will be an electric shock or misoperation.
- Perform correct wiring for the module according to the product's rated voltage and terminal arrangement. Connecting to a power supply different from rating or miss-wiring may cause fire and/or product failure.
- Ensure that no foreign matter such as chips and wire-offcuts enter the module. Foreign matter can cause a fire, failure or malfunction.

CAUTION


- Be sure that the communication cable connected to the module is kept in the duct or is fixed with cramps.
Failure to do so may cause a damage to the module or cables due to dangling, shifting or inadvertent handling of cable, or malfunction because of bad cable contacts.
- Do not grab on the cable when removing the communication cable connected to the module.
When removing the cable with a connector, hold the connector on the side that is connected to the module.
- Do not install the control lines together with the communication cables, or bring them close to each other.
Failure to do so may cause malfunctions due to noise.
- Do not disassemble or modify the modules.
Doing so could cause failure, erroneous operation, injury, or fire.
- Before cleaning, retightening the terminal block or module fixing screws, or installing/removing a module, be sure to shut off all phases of the external power supply used in the system.
Not doing so can cause the module to fail or malfunction.
- Do not install/remove the terminal block more than 50 times after the first use of the product. (IEC 61131-2 compliant)
- Before handling the module, make sure to touch a grounded metal object to discharge the static electricity from the human body.
Failure to do so may cause a failure or malfunctions of the module.
- When disposing of this product, treat it as industrial waste.

- (1) Tighten module installation screws within the torque range below.
Do not over-tighten these screws. The screws and module case may be damaged.

Table 4.1 Specified torque range for each screw

Screw location	Specified torque range
Module installation screw (M4 screws)	0.78 to 1.08N•m
Terminal block fixing screw	0.4 to 0.5N•m (conforming to IEC 60999)

- (2) When a DIN rail is used, install it taking care with the following.
- Applicable DIN rail type (conforming to IEC 60715)
TH35-7.5Fe
TH35-7.5Al
 - Intervals of DIN rail mounting screws
Mount the DIN rail by fixing it with mounting screws at intervals of 200 mm (7.87inch) or shorter.
- (3) To mount the AJ65BTS-RPH to the DIN rail, hitch the upper hook of the module to the DIN rail securely and push the module into the DIN rail.
(Push the module until the lower hook of the module clicks.)




- (4) When installing the AJ65BTS-RPH module on the control panel, to improve the ventilation and facilitate the replacement of the module, provide a distance of 60 mm (2.36inch) or longer between the upper and lower surfaces of the module and the structural members or parts.
- (5) Install the AJ65BTS-RPH module on a flat smooth surface.
If there are irregularities on the installation surface, undue force may be applied to the printed circuit boards, and the boards may be damaged.

- (6) Depending on the grounding condition of the system, a high-frequency noise may occur between the systems. When these systems are connected through CC-Link communication cables, a communication error may occur by the mixing of noise into the repeaters. If the high-frequency noise occurs between the systems connected through the cables of 10 m (32.79ft.) or shorter, take either of the measures specified below.

Method1: Connect the systems through cables of 2 mm² or larger (across FG terminals of the remote station in each system, or across grounds of the control panel to which the remote station is grounded).


Method2: Use CC-Link cables of 10 m (32.79ft.) or longer between the systems.



(7) Stripping the cable end


- (a) The cable strip length must be approx. 10mm. If the cable is stripped too much, conductors may stick out of the terminal block and may cause an electric shock or short circuit with an adjacent terminal block.

If the stripped length is too short, sufficient contact may not be ensured.





- (b) For use of bar terminals, pay attention to the following:

- 1) Select a bar terminal suitable for the cable size.
- 2) Use an appropriate crimp tool to crimp the bar terminal.
- 3) Insert the cable so that cable cores will stick out 0 to 0.5mm from the sleeve edge.



- 4) Check the appearance of the bar terminal after crimping. If it is not crimped properly or is damaged on the side, do not use the terminal. (See the following illustrations.)




(8) Connecting the cable to the spring clamp terminal block

(a) Connecting the cable

While pressing the open/close button with a flat-head screwdriver, insert the cable into the insertion hole.

- 1) For use of bar terminals, the cable can be inserted without pressing the open/close button.



(b) Disconnecting the cable

While fully pressing the open/close button with the flat-head screwdriver, pull out the cable.

4.2.2 Installation environment

For installation environment, refer to Section 3.1.

4.3 Names and settings of parts

The names of parts of the AJ65BTS-RPH module, indication statuses of LEDs, and settings of switches are described below.




Table 4.2 Names and settings of parts (1/3)

No.	Name	Application	
1)	Operation status display LED	Check for the module condition by observing the state of lighting of the LED.	
		LED Name	Application
		POWER	ON : Power supply on OFF : Power supply off
		RUN	ON : Module is operating normally OFF : Module is not operating normally
		SD LINK IN/OUT	ON : Data are being sent to the LINK IN or LINK OUT of the trunk line OFF : Data are not being sent to the LINK IN or LINK OUT of the trunk line
		RD LINK IN/OUT	ON : Data are being received from the LINK IN or LINK OUT of the trunk line OFF : Data are not being received from the LINK IN or LINK OUT of the trunk line
		ERR.	ON : Transmission rate setting out-of-range error or communication error occurred Flickering : Terminating resistor is missing. The module and CC-Link cables are affected by noise. Or the transmission rate was changed after power up. OFF : Module is operating normally
		RD LINK 1 to 8	ON : Data are being received from the LINK1 to 8 of the branch line. OFF : Data are not being received from the LINK1 to 8 of the branch line.

Table 4.2 Names and settings of parts (2/3)








No.	Name	Application														
2)	Transmission rate setting switch	Set the transmission rate of the module (set to 0 at the time of delivery). Ensure to set the transmission rate at a speed specified below. Transmission rate of the trunk line side is identical with that of the branch line side.														
		<table><tr><th>Setting value</th><th>Transmission rate (bps)</th></tr><tr><td>0</td><td>156k</td></tr><tr><td>1</td><td>625k</td></tr><tr><td>2</td><td>2.5M</td></tr><tr><td>3</td><td>5M</td></tr><tr><td>4</td><td>10M</td></tr><tr><td>Other than 0 to 4</td><td>Cannot be set. If set to other than 0 to 4, the ERR. LED is turned on and data are not transferred.</td></tr></table>	Setting value	Transmission rate (bps)	0	156k	1	625k	2	2.5M	3	5M	4	10M	Other than 0 to 4	Cannot be set. If set to other than 0 to 4, the ERR. LED is turned on and data are not transferred.
		Setting value	Transmission rate (bps)													
		0	156k													
		1	625k													
		2	2.5M													
		3	5M													
		4	10M													
Other than 0 to 4	Cannot be set. If set to other than 0 to 4, the ERR. LED is turned on and data are not transferred.															
3)	Power terminal block	Connects the module power supply (24V DC) and the ground cable (FG: Functional Ground). Terminals are assigned as follows:														
		<table><tr><td></td><td><table><tr><td>+24V</td><td>+24V</td></tr><tr><td>24G</td><td>24G</td></tr><tr><td>NC</td><td>NC</td></tr><tr><td>FG</td><td>FG</td></tr><tr><td>FG</td><td>FG</td></tr></table></td></tr></table>		<table><tr><td>+24V</td><td>+24V</td></tr><tr><td>24G</td><td>24G</td></tr><tr><td>NC</td><td>NC</td></tr><tr><td>FG</td><td>FG</td></tr><tr><td>FG</td><td>FG</td></tr></table>	+24V	+24V	24G	24G	NC	NC	FG	FG	FG	FG		
	<table><tr><td>+24V</td><td>+24V</td></tr><tr><td>24G</td><td>24G</td></tr><tr><td>NC</td><td>NC</td></tr><tr><td>FG</td><td>FG</td></tr><tr><td>FG</td><td>FG</td></tr></table>	+24V	+24V	24G	24G	NC	NC	FG	FG	FG	FG					
+24V	+24V															
24G	24G															
NC	NC															
FG	FG															
FG	FG															
4)	Communication terminal block (Trunk line side)	Connects the transmission lines on the trunk line side (LINK IN/OUT). Terminals are assigned as follows:														
		<table><tr><td></td><td><table><tr><td>DA</td><td>DA</td></tr><tr><td>DB</td><td>DB</td></tr><tr><td>DG</td><td>DG</td></tr><tr><td>SLD</td><td>SLD</td></tr></table></td></tr></table>		<table><tr><td>DA</td><td>DA</td></tr><tr><td>DB</td><td>DB</td></tr><tr><td>DG</td><td>DG</td></tr><tr><td>SLD</td><td>SLD</td></tr></table>	DA	DA	DB	DB	DG	DG	SLD	SLD				
	<table><tr><td>DA</td><td>DA</td></tr><tr><td>DB</td><td>DB</td></tr><tr><td>DG</td><td>DG</td></tr><tr><td>SLD</td><td>SLD</td></tr></table>	DA	DA	DB	DB	DG	DG	SLD	SLD							
DA	DA															
DB	DB															
DG	DG															
SLD	SLD															

Table 4.2 Names and settings of parts (3/3)


No.	Name	Application				
5)	Communication terminal block (Branch line side)	<p>Connects the transmission lines on the branch line side (LINK 1 to 8). Terminals are assigned as follows:</p> <div><table><tr><td>DA</td></tr><tr><td>DB</td></tr><tr><td>DG</td></tr><tr><td>SLD</td></tr></table></div>	DA	DB	DG	SLD
DA						
DB						
DG						
SLD						
6)	Module fixing hole	Screw hole for fixing the module.				
7)	Terminal block fixing screw	Screw for fixing the terminal block.				

POINT

Set the same transmission rate as that of the master station.

4.4 Connection of module through CC-Link dedicated cable

The method of connecting the AJ65BTS-RPH module to the CC-Link system through the CC-Link dedicated cable is shown below.



For (1) to (5) shown in the above, read the following cautions on connections.

- (1) For the segment connected to the trunk line side of the AJ65BTS-RPH, connect a terminating resistor to the module connected at the end.
Select a type for terminating resistor in accordance with the type of the connected communication cable.
For details, refer to the manual of the module connected.
- (2) Do not connect any terminating resistor to the AJ65BTS-RPH when the trunk line side is connected to a station that is not located at the end of the segment.
In addition, connect the shielding wire of the CC-Link dedicated cable to "SLD" of each module, and ground both ends via "FG" The interval between SLD and FG is connected in the module in advance.
- (3) Connect the included terminating resistor to the AJ65BTS-RPH when the trunk line side is connected to a station that is located at the end of the segment.
Select a type for terminating resistor in accordance with the type of the connected communication cable.
For details, refer to Section 2.2.
In addition, connect the shielding wire of the CC-Link dedicated cable to "SLD" of each module, and ground both ends via "FG" The interval between SLD and FG is connected in the module in advance.

- (4) Connect the included 110Ω terminating resistor to the module located at the end of a segment when the branch line side of the AJ65BTS-RPH is connected to the segment.
For the connection of terminal resistor, refer to the manual of the module connected.
- (5) For the branch line side of the AJ65BTS-RPH, use the incorporated 110Ω terminating resistor.
In addition, connect the shielding wire of the CC-Link dedicated cable to "SLD" of each module, and ground both ends via "FG".
Note that SLD and FG are connected to each other in the module.

4.5 Check for state of connection (line test)

Connect all modules including the AJ65BTS-RPH module through the CC-Link dedicated cable. Then, check that the CC-Link system is in the state capable of performing a data link normally.


Because whether or not a master station can establish a data link with a particular slave station can be checked by the connection status check (circuit test), an error module can be identified.


For the connection status check (circuit test), perform the circuit test 1 of the master module. If an error is detected, perform the circuit test 2 of the master module.

For the details of circuit tests 1 and 2, refer to the user's manual of the master module used.

Perform the test following the steps shown below.

POINT
Perform the circuit test 2 of the master module by selecting the target stations as described in (1) to (3) below.
(1) In the segment including the master module, select slave stations in order from the nearest to the master module to the farthest.
(2) In the segment (1st stage), select slave stations in order from the nearest to the AJ65BTS-RPH to the farthest.
(3) In the segment (2nd stage), select slave stations in order from the nearest to the AJ65BTS-RPH to the farthest.





5. TROUBLESHOOTING

This section describes the measures when a trouble occurred in the AJ65BTS-RPH.


Perform the troubleshooting indicated in the reference section.

No.*1	Problem	Reference section
1	The POWER LED is not lit while the module power is ON.	(1) in this chapter
2	The RUN LED is not lit while the module power is ON.	(2) in this chapter
3	The ERR. LED lighted up or blinked.	(3) in this chapter
4	The RD LINK IN/OUT LED does not light up during data link.	(4) in this chapter
5	The RD LINK 1 to 8 LEDs corresponding to the data linking branch lines do not light up.	(5) in this chapter

*1 If more than one problem occurred simultaneously, perform the troubleshooting in order of the item numbers.

(1) The POWER LED is not lit while the module power is ON

Troubleshooting is shown below for the case that the POWER LED is not lit while the module power is ON.




- (2) The RUN LED is not lit while the module power is ON.

If the RUN LED is not lit while the module power is ON, turn off and on the module again.

If the RUN LED is not lit after the module power is reapplied, the hardware may be faulty. Please contact your local Mitsubishi representative.


- (3) The ERR. LED lights up or blinks.

Troubleshooting is shown below for the case that the ERR. LED lights up or blinks.




(4) The RD LINK IN/OUT LED is not lit during data link.

This section describes troubleshooting for the case that the RD LINK IN/OUT LED is not lit.




- (5) The RD LINK 1 to 8 LEDs corresponding to the data linking branch lines are not lit.

This section describes troubleshooting when the RD LINK 1 to 8 LEDs corresponding to the data linking branch lines are not lit.



6. EXTERNAL DIMENSIONS

The external dimensions of AJ65BTS-RPH module is shown below.



Warranty

Mitsubishi will not be held liable for damage caused by factors found not to be the cause of Mitsubishi; machine damage or lost profits caused by faults in the Mitsubishi products; damage, secondary damage, accident compensation caused by special factors unpredictable by Mitsubishi; damages to products other than Mitsubishi products; and to other duties.

⚠ For safe use

- This product has been manufactured as a general-purpose part for general industries, and has not been designed or manufactured to be incorporated in a device or system used in purposes related to human life.
- Before using the product for special purposes such as nuclear power, electric power, aerospace, medicine or passenger movement vehicles, consult with Mitsubishi.
- This product has been manufactured under strict quality control. However, when installing the product where major accidents or losses could occur if the product fails, install appropriate backup or failsafe functions in the system.

Country/Region	Sales office/Tel	Country/Region	Sales office/Tel
U.S.A	Mitsubishi Electric Automation Inc. 500 Corporate Woods Parkway Vernon Hills, IL 60061, U.S.A. Tel : +1-847-478-2100	Hong Kong	Mitsubishi Electric Automation (Hong Kong) Ltd. 10th Floor, Manulife Tower, 169 Electric Road, North Point, Hong Kong Tel : +852-2887-8870
Brazil	MELCO-TEC Rep. Com.e Assessoria Tecnica Ltda. Rua Correia Dias, 184, Edifício Paraiso Trade Center-8 andar Paraiso, Sao Paulo, SP Brazil Tel : +55-11-5908-8331	China	Mitsubishi Electric Automation (Shanghai) Ltd. 4/F Zhi Fu Plaza, No.80 Xin Chang Road, Shanghai 200003, China Tel : +86-21-6120-0808
Germany	Mitsubishi Electric Europe B.V. German Branch Gothaer Strasse 8 D-40880 Ratingen, GERMANY Tel : +49-2102-486-0	Taiwan	Setsuyo Enterprise Co., Ltd. 6F No.105 Wu-Kung 3rd Rd, Wu-Ku Hsiang, Taipei Hsine, Taiwan Tel : +886-2-2299-2499
U.K	Mitsubishi Electric Europe B.V. UK Branch Travellers Lane, Hatfield, Hertfordshire., AL10 8XB, U.K. Tel : +44-1707-276100	Korea	Mitsubishi Electric Automation Korea Co., Ltd. 1480-6, Gayang-dong, Gangseo-ku Seoul 157-200, Korea Tel : +82-2-3660-9552
Italy	Mitsubishi Electric Europe B.V. Italian Branch Centro Dir. Colleoni, Pal. Perseo-Ingr.2 Via Paracelo 12, I-20041 Agrate Brianza., Milano, Italy Tel : +39-039-60531	Singapore	Mitsubishi Electric Asia Pte, Ltd. 307 Alexandra Road #05-01/02, Mitsubishi Electric Building, Singapore 159943 Tel : +65-6470-2460
Spain	Mitsubishi Electric Europe B.V. Spanish Branch Carretera de Rubi 76-80, E-08190 Sant Cugat del Valles, Barcelona, Spain Tel : +34-93-565-3131	Thailand	Mitsubishi Electric Automation (Thailand) Co., Ltd. Bang-Chan Industrial Estate No.111 Moo 4, Serithai Rd, T.Kannayao, A.Kannayao, Bangkok 10230 Thailand Tel : +66-2-517-1326
France	Mitsubishi Electric Europe B.V. French Branch 25, Boulevard des Bouvets, F-92741 Nanterre Cedex, France TEL : +33-1-5568-5568	Indonesia	P.T. Autoteknindo Sumber Makmur Muara Karang Selatan, Block A/Utara No.1 Kav. No.11 Kawasan Industri Pergudangan Jakarta - Utara 14440, P.O.Box 5045 Jakarta, 11050 Indonesia Tel : +62-21-6630833
South Africa	Circuit Breaker Industries Ltd. Private Bag 2016, ZA-1600 Isando, South Africa Tel : +27-11-928-2000	India	Messung Systems Pvt. Ltd. Electronic Sadan NO:III Unit No15, M.I.D.C. Bhosari, Pune-411026, India Tel : +91-20-2712-3130
		Australia	Mitsubishi Electric Australia Pty. Ltd. 348 Victoria Road, Rydalmere, N.S.W 2116, Australia Tel : +61-2-9684-7777



MITSUBISHI ELECTRIC CORPORATION

HEAD OFFICE : TOKYO BUILDING, 2-7-3 MARUNOUCHI, CHIYODA-KU, TOKYO 100-8310, JAPAN
NAGOYA WORKS : 1-14, YADA-MINAMI 5-CHOME, HIGASHI-KU, NAGOYA, JAPAN

When exported from Japan, this manual does not require application to the Ministry of Economy, Trade and Industry for service transaction permission.

Specifications subject to change without notice.
Printed in Japan on recycled paper.