


## 2. 各部の名称と設定

## 2. Part Names and Settings



No.	名称	内 容	
		LED名	確認内容
①	動作表示 LED	PW	点灯: 電源ON 消灯: 電源OFF
		L RUN	点灯: 交信正常時 消灯: 交信断時 (タイムオーバエラー)
		L ERR.	点灯: 交信エラー時 一定間隔で点滅: 通電中に局番設定／伝送速度設定スイッチの設定を変更したとき  不定間隔で点滅: 終端抵抗の設定が違っているとき ユニット、CC-Link専用ケーブルがノイズの影響を受けているとき 消灯: 交信正常時
		X0~F	点灯: 入力ON 消灯: 入力OFF
②	伝送速度 設定	設定値	設定スイッチ状態
		4 1 2 3 4	2 1 OFF OFF ON OFF OFF
③	局番設定 スイッチ	4 1 2 3 32	OFF OFF ON ON OFF ON OFF ON OFF
		40 20 10 8 4 2 1	20 10 8 4 2 1
④	端子台	入力ユニット電源、伝送、入力信号の接続用端子台です。	
⑤	DINレール 用ソック	ユニットをDINレールに取り付けるときにDINレール用フックの中心線上を指でカチッと音がするまで押さえます。	

\*1 局番は重複して設定できません。

本マニュアルは再生紙を使用しています。

## AJ65SBTB3-16D 形 CC-Link システム小形タイプリモート I/O ユニットユーザーズマニュアル AJ65SBTB3-16D CC-Link System Compact Type Remote I/O Module User's Manual

### ● 安全上のご注意 ● (ご使用前に必ずお読みください)

本製品のご使用に際しては、本マニュアルをよくお読みいただくと共に、安全に対して十分に注意を払って、正しい取扱いをしていただくようお願いいたします。

なお、この注意事項は本製品に関するもののみについて記載したものです。シーケンサシステムとしての安全上の注意に関しては、CPUユニットのユーザーズマニュアルを参照してください。

この●安全上のご注意●では、安全注意事項のランクを「危険」、「注意」として区分しております。

	危険	取扱いを誤った場合に、危険な状況が起こりえて、死亡または重傷を受ける可能性が想定される場合。
	注意	取扱いを誤った場合に、危険な状況が起こりえて、中程度の傷害や軽傷を受ける可能性が想定される場合および物的損害だけの発生が想定される場合。

なお、△ 注意に記載した事項でも、状況によっては重大な結果に結びつく可能性があります。

いずれも重要な内容を記載していますので必ず守ってください。  
本マニュアルは必要なときに読めるように大切に保管すると共に、必ず最終ユーザまでお届けいただくようにお願いいたします。

### 【設計上の注意事項】

No.	Item	Description
	LED name	Confirmation details
	PW	ON: Power supply ON OFF: Power supply OFF
	L RUN	ON: Normal communication OFF: Communication shut off (time expiration error)
①	Operating status indicator LEDs	ON: Communication data error Flash at regular intervals: Indicates that the station number setting or transmission speed setting switch position was changed while power is ON L ERR. ON: Communication data error Flash at irregular intervals: When the setting of the terminal resistor is wrong; when the cable for the module or CC-Link is affected by noise OFF: Normal communication
	X0 to F	ON: Input ON OFF: OFF

②	Transmission speed setting	Setting value	Setting switch status	Transmission speed
		4	2	1
		0	OFF OFF	OFF 156 kbps
		1	OFF OFF	ON 625 kbps
		2	OFF ON	OFF 2.5 Mbps
		3	OFF ON	ON 5.0 Mbps
		4	ON OFF	OFF 10 Mbps

Be sure to set the transmission speed within the above range.

③	Station number setting switches	Select "10", "20" or "40" to set the tens place of the station number. Select "1", "2", "4" or "8" to set the ones place of the station number. Always set the station number within the range of 1 to 64. (*) Example) Set the switches as below when setting the station number to 32:	Station number	Tens place	Ones place
			40 20 10 8 4 2 1	OFF ON ON OFF OFF ON OFF	
			32	OFF ON ON OFF OFF ON OFF	

④	Terminal block	A terminal block for connection to the power supply, transmission and input signals.
		When the module is installed to the DIN rail, push on the center line of the hook for DIN rail with a finger tip until a clicking sound is heard.

\*1 Duplicate station number cannot be set.

Printed in Japan on recycled paper.

### ● SAFETY PRECAUTIONS ● (Read these precautions before using.)

When using this equipment, thoroughly read this manual. Also pay careful attention to safety and handle the module properly.

These precautions apply only to this equipment. Refer to the CPU module user's manual for a description of the PLC system safety precautions.

These ● SAFETY PRECAUTIONS ● classify the safety precautions into two categories: "DANGER" and "CAUTION".

	DANGER	Procedures which may lead to a dangerous condition and cause death or serious injury if not carried out properly.
	CAUTION	Procedures which may lead to a dangerous condition and cause superficial to medium injury, or physical damage only, if not carried out properly.

Depending on circumstances, procedures indicated by △ CAUTION may also result in to serious results.

In any case, it is important to follow the directions for usage.  
Store this manual in a safe place so that you can take it out and read it whenever necessary. Always forward it to the end user.

(0705) MEE

### 【DESIGN PRECAUTIONS】

#### ! DANGER

- When a communication error occurs in the data link, the communication error station will be in the following condition. Configure an interlocking circuit in a sequence program using the communication status information so that the safety of the overall system is always maintained. Accident may occur due to output error or malfunction. Input points from remote I/O station will be all switched off.
- Input could be switched on or off when a problem occurs in the remote I/O modules. So build an external monitoring circuit that will monitor any input signals that could cause a serious accident.

#### ! CAUTION

- Use each module in an environment as specified in the "general specification" in the CPU module user's manual. Usage of the module outside the general specification range may cause electric shock, fire, malfunction, product damage or deterioration.
- Do not have control cables and communication cables bundled with or placed near by the main circuit and/or power cables. Wire those cables at least 100mm(3.94 inch) away from the main circuit and/or power cables. It may cause malfunction due to noise interference.

### 【INSTALLATION PRECAUTIONS】

#### ! CAUTION

- Do not directly touch the module's conductive parts. Doing so could cause malfunction or trouble in the module.
- Tighten the module securely using DIN rail or installation screws within the specified torque range. Loose terminal screws may cause a short circuit or erroneous operation. If the terminal screws are too tight, it may cause falling, short circuit or erroneous operation due to damage of the screws.

### 【WIRING PRECAUTIONS】

#### ! DANGER

- Completely turn off the externally supplied power used in the system when installing or placing wiring. Not completely turning off all power could result in electric shock or damage to the product.

## △注意

- FG端子はシーケンサ専用のD種接地（第三種接地）以上で必ず接地を行ってください。  
感電、誤動作の恐れがあります。
- 空き端子ネジは必ず締付けトルク範囲（42～50N·cm）で締付けてください。  
圧着端子と短絡する原因になります。
- 圧着端子は適合圧着端子を使用し、規定のトルクで締付けてください。  
先開形圧着端子を使用すると、端子ネジがゆるんだ場合に脱落し、故障の原因になります。
- ユニットの配線は、製品の定格電圧および端子配列を確認した上で正しく行ってください。  
定格と異なる電源を接続したり、誤記線になると、火災、故障の原因になります。
- 端子ネジの締付けは、規定トルク範囲内で行ってください。  
端子ネジを締め過ぎると、ネジの破損による短絡、誤動作の原因になります。
- ユニット内に、切片やケーブル等の異物が入らないように注意してください。  
火災、故障の原因になります。
- ユニットに接続する電線やケーブルは、必ずダクトに納める、またはクランプによる固定処理を行ってください。  
ケーブルをダクトに納めなかつたり、クランプによる固定処理をしていないと、ケーブルのブリッジや移動、不注意の引張りなどによるユニットやケーブルの破損、ケーブルの接続不良による誤動作の原因となります。
- 制御線と通信ケーブルは束線したり、近接したりしないでください。
- ユニットに接続されたケーブルを取り外すときは、ケーブル部分を手に持つて引っ張らないでください。コネクタ付きのケーブルは、ユニットに接続している部分のコネクタを手で持って取り外してください。コネクタなしのケーブルは、ユニットに接続している部分のネジを緩めてから取り外してください。  
ユニットに接続された状態でケーブルを引っ張ると、ユニットやケーブルの破損、ケーブルの接続不良による誤動作の原因となります。

## 【立上げ・保守時の注意事項】

### △危険

- 通電中に端子に触れないでください。感電の原因になります。
- 清掃、端子ネジ、ユニット取付けネジの増し締めは、必ずシステムで使用している外部供給電源を全相遮断してから行ってください。全相遮断ないと、ユニットの故障や誤動作の原因になります。

### △注意

- ユニットの分解、改造はしないでください。  
故障、誤動作、ケガ、火災の原因になります。
- ユニットは落下させたり、強い衝撃を与えないでください。  
ユニットの破損の原因になります。
- ユニットの蓋への取付け・取外しは必ずシステムで使用している外部供給電源を全相遮断してから行ってください。全相遮断ないと、ユニットの故障や誤動作の原因になります。
- 開けた蓋の着脱は、製品ご使用後、50回以内としてください。  
(JIS B 3502準拠)
- ユニットに触れる前には、必ず接地された金属などに触れて、人体などに帯電している静電気を放電してください。  
静電気を放電しないと、ユニットの故障や誤動作の原因になります。

## 【廃棄時の注意事項】

### △注意

- 製品を廃棄するときは、産業廃棄物として扱ってください。

## 1.仕様

項目	内容
入力点数	16点
絶縁方式	フォトカプラ絶縁
定格入力電圧	DC24V
定格入力電流	約7mA
使用電圧範囲	DC19.2~26.4V (リップル率5%以内)
最大同時入力点数	100%
ON電圧/ON電流	14V以上/1.5mA以上
OFF電圧/OFF電流	6V以下/1.7mA以下
入力抵抗	約3.3kΩ
応答時間	OFF→ON: 1.5ms以下 (DC24V時) ON→OFF: 1.5ms以下 (DC24V時)
コモン方式	16点コモン (端子台形3線式) プラス、マイナスコモン共用タイプ (シンク、ソース共用タイプ)
入力形式	32点割付け (16点使用)
占有局数	1局
I/Oユニット電源	電圧 DC20.4~26.4V (リップル率5%以内) 電流 45mA以下 (DC24V, 全点ON時)

## △CAUTION

- Always ground the FG terminal.  
There is a risk of electric shock or malfunction.
- Be sure to tighten any unused terminal screws within a tightening torque range (42 to 50 N·cm). Failure to do so may cause a short circuit due to contact with a solderless terminal.
- Use applicable solderless terminals and tighten them with the specified torque.  
If any solderless spade terminal is used, it may be disconnected when the terminal screw comes loose, resulting in failure.
- Perform correct wiring for the module according to the product's rated voltage and terminal arrangement. Connecting to a power supply different from rating or miss-wiring may cause fire and/or product failure.
- Fix terminal screws securely within the regulated torque. Loose terminal screws may cause fire and/or malfunction.  
If the terminal screws are too tight, it may cause short circuit or erroneous operation due to damage of the screws.
- Make sure foreign objects do not get inside the module, such as dirt and wire chips. It may cause fire, product failure or malfunction.
- Be sure to fix the wires or cables by ducts or clamps when connecting them to the module. Failure to do so may cause damage of the module or the cables due to accidental pull or unintentional shifting of the cables, or malfunctions due to poor contact of the cable.
- Do not install the control lines together with the communication cables, or bring them close to each other. Failure to do so may cause malfunctions due to noise.
- When disconnecting a cable from the module, do not pull on the cable itself. Disconnect cables not fitted with a connectors by holding and pulling the cable connector. Disconnect cables not fitted with a connector by removing the screws from the part connected to the module can cause damage to the module or cable, or malfunction due to cable connection faults.

## 【STARTING AND MAINTENANCE PRECAUTIONS】

### △DANGER

- Do not touch terminals when the power is on. Doing so could cause an electric shock.
- Switch off all phases of the externally supplied power used in the system when cleaning the module or retightening the terminal or module mounting screws. Not doing so could result in electric shock.

### △CAUTION

- Never try to disassemble or modify module. It may cause product failure, malfunction, fire or cause injury.
- Do not drop or apply any strong impact to the module. Doing so may damage the module.
- Completely turn off the externally supplied power used in the system before mounting or removing the module to/from the panel. Not doing so could result in damage to the product.
- Mounting/removing the terminal block is limited to 50 times after using a product. (IEC61131-2-compliant)
- Always make sure to touch the grounded metal to discharge the electricity charged in the electricity charged in the body, etc., before touching the module. Failure to do so may cause a failure or malfunctions of the module.

## 【DISPOSAL PRECAUTIONS】

### △CAUTION


- When disposing of this product, treat it as industrial waste.

## 1. Specification

Item	Description
Number of input points	16 points
Isolation method	Photocoupler
Rated input voltage	24 V DC
Rated input current	Approx. 7 mA
Operating voltage range	19.2 to 26.4 V DC (ripple ratio: within 5 %)
Max. simultaneous ON input points	100 %
ON voltage/ON current	14 V or higher/3.5 mA or higher
OFF voltage/OFF current	6 V or lower/1.7 mA or lower
Input resistance	Approx. 3.3 kΩ
Response time	OFF→ON: 1.5 ms or lower (when 24 V DC) ON→OFF: 1.5 ms or lower (when 24 V DC)
Wiring method for common	16 points/common (terminal block 3-wire type)
Input form	Positive/Negative common shared type (sink/source shared type)
Number of stations occupied	1 station 32 points assignment (use 16 points)
I/O module power supply	Voltage 20.4 to 26.4 V DC (ripple ratio: within 5 %) Current 45 mA or lower (when 24 V DC, all points ON)

項目	内容
ノイズ耐量	DC タイプのノイズ電圧 500Vp-p, ノイズ幅 1μs, ノイズ周波数 25~60 Hz のノイズシミュレータによる
耐電圧	DC 外部端子一括ーアース間 AC500V 1 分間
絶縁抵抗	DC 外部端子一括ーアース間 DC500V 絶縁抵抗計にて 10MΩ 以上
保護等級	IP2X
質量	0.25kg
外部接続方式	通信部、I/O ユニット電源部 7点 2 ピース端子台 【伝送回路、I/O ユニット電源、FG】 M3×5.2 締付けトルク範囲：59～88N·cm 適合圧着端子の挿入枚数は2枚以内
外部接続方式	入出力電源部、入出力部 34点直付け端子台 【入出力電源、I/O 信号】 M3×5.2 締付けトルク範囲：59～88N·cm 適合圧着端子の挿入枚数は2枚以内
ユニット取付けネジ	平座金みがき丸付 M4 ネジ 【締付けトルク範囲：79～108N·cm】 DIN レールでの取付け可、6 方向取付け可
適用 DIN レール	TH35-7.5Fe, TH35-7.5Ai (JIS C 2812に準拠)
適合圧着端子	・RAV1.25-3 (JIS C 2805に準拠) ・V2-MS3 (日本圧着端子製造(株))、RAP2-3SL (日本端子(株)), TGV2-3N (株ニチフ) 【適合電線サイズ：0.3～1.25mm²】 ・V2-MS3, RAP2-3SL, TGV2-3N 【適合電線サイズ：1.25～2.0mm²】
External wiring system	34-point direct-mount terminal block 【I/O power supply, I/O signal】 M3×5.2 Tightening torque range: 59 to 88 N·cm Applicable solderless terminals: 2 max.
Module installation screw	M4 screw with plain washer finished round (tightening torque range: 79 to 108 N·cm) Module can be mounted using DIN rail and can be mounted in 6 directions
Applicable DIN rail	TH35-7.5Fe, TH35-7.5Ai (conforming to IEC 60715)
Applicable solderless terminal	RAV1.25-3 (conforming to JIS C 2805) 【Applicable wire size: 0.3 to 1.25 mm²】 ・V2-MS3, RAP2-3SL, TGV2-3N 【Applicable wire size: 1.25 to 2.0 mm²】

外部接続 (External connection)



端子番号 Terminal number	信号名 Signal name	端子番号 Terminal number	信号名 Signal name
TB1	DA	TB21	COM A
TB2	DB	TB22	X7
TB3	DG	TB23	COM B
TB4	SLD	TB24	X8
TB5	+24V	TB25	COM A
TB6	(FG)	TB26	X9
TB7	24G	TB27	COM B
TB8	X0	TB28	XA
TB9	COM A	TB29	COM A
TB10	X1	TB30	XB
TB11	COM B	TB31	COM B
TB12	X2	TB32	XC
TB13	COM A	TB33	COM A
TB14	X3	TB34	XD
TB15	COM B	TB35	COM B
TB16	X4	TB36	XE
TB17	COM A	TB37	COM A
TB18	X5	TB38	XF
TB19	COM B	TB39	COM B
TB20	X6	TB40	DC24A
			TB41 DC24B