## **CJ-series Position Control Units with EtherCAT interface**

## **CJ1W-NC** 81/ 82

CSM\_CJ1W-NC\_81\_E\_7\_2

# Preeminent control performance and easy operation feature of EtherCAT improve the production efficiency.

The EtherCAT communications with 100Mbps baud rate enables fast and accurate position control.

A wide range of position control functions are available with this position control unit.





**CJ1W-NC881** 


**CJ1W-NC882** 

Sysmac is a trademark or registered trademark of OMRON Corporation in Japan and other countries for OMRON factory automation products. Windows is either registered trademarks or trademarks of Microsoft Corporation in the United States and/or other countries. EtherCAT® is registered trademark and patented technology, licensed by Beckhoff Automation GmbH, Germany. Other company names and product names in this document are the trademarks or registered trademarks of their respective companies.

#### **Features**

- Fast positioning operation: taking from 0.15 to 0.4ms (min.) to start servo operation from PLC start command.
- Support for Servomotors with Absolute Encoders
- Monitor the Deviation between Axes during Linear Interpolation
- A Wide Range of Positioning Operations
- Comes with Memory Operation function.
- Common control interface with pulse-train type position control unit (CJ1W-NC□□4).
- Fast communication of EtherCAT (250µs min. communications cycle).
- In addition to servo control, inverters, vision sensors, and other I/O devices that support EtherCAT can be connected.
- Support for Servomotors Speed Control and Torque limit outputs.
- A wide variety of Electronic Cam Synchronization applications (CJ1W-NC□82)

## **System Configuration**



### **Ordering Information**

#### **International Standards**

- The standards are abbreviated as follows: U: UL, U1: UL(Class I Division 2 Products for Hazardous Locations), C: CSA, UC: cULus, UC1: cULus (Class I Division 2 Products for Hazardous Locations), CU: cUL, N: NK, L: Lloyd, and CE: EC Directives.
- Contact your OMRON representative for further details and applicable conditions for these standards.

#### **Position Control Units with EtherCAT interface**

Unit toma	Product	Specifications	No. of unit	Current consumption (A)		) Model	Standards	
Unit type	Name	Control output interface	No. of axes	allocated	5 V	24 V	Model	Standards
			2 axes	-			CJ1W-NC281	
		Control commands executed by EtherCAT communications. Positioning functions: Memory operation, Direct operation by ladder programming  Control commands executed by EtherCAT communications. Positioning functions: Memory operation, Direct operation by ladder programming	4 axes		0.46	_	CJ1W-NC481	UC1, CE
	Position Control		8 axes				CJ1W-NC881	
0.14.0011			16 axes				CJ1W-NCF81	
CJ1 CPU Bus Units	Units with EtherCAT interface		4 axes			-	CJ1W-NC482	
			8 axes				CJ1W-NC882	
		I/O communications: 64 nodes	16 axes				CJ1W-NCF82	

Note: 1. There is no accessory for the CJ-series Position Control Unit with EtherCAT interface.

2. This unit cannot be used, with the Machine Automation Controller NJ-series.

#### **Recommended EtherCAT Communications Cables**

Use Straight STP (shielded twisted-pair) cable of category 5 or higher with double shielding (braiding and aluminum foil tape) for EtherCAT.

#### **Cabel with Connectors**

Item	Appearance	Recommended manufacturer	Cable length(m)	Model
			0.3	XS6W-6LSZH8SS30CM-Y
Standard type			0.5	XS6W-6LSZH8SS50CM-Y
Cable with Connectors on Both Ends (RJ45/RJ45)		OMBON	1	XS6W-6LSZH8SS100CM-Y
Wire Gauge and Number of Pairs: AWG27, 4-pair Cable Cable Sheath material: LSZH *2		OMRON	2	XS6W-6LSZH8SS200CM-Y
Cable color: Yellow *3			3	XS6W-6LSZH8SS300CM-Y
			5	XS6W-6LSZH8SS500CM-Y
			0.3	XS5W-T421-AMD-K
	_		0.5	XS5W-T421-BMD-K
Rugged type	100	OMRON	1	XS5W-T421-CMD-K
Cable with Connectors on Both Ends (RJ45/RJ45) Wire Gauge and Number of Pairs: AWG22, 2-pair Cable			2	XS5W-T421-DMD-K
			5	XS5W-T421-GMD-K
			10	XS5W-T421-JMD-K
			0.3	XS5W-T421-AMC-K
			0.5	XS5W-T421-BMC-K
Rugged type	-	OMBON	1	XS5W-T421-CMC-K
Cable with Connectors on Both Ends (M12 Straight/RJ45) Wire Gauge and Number of Pairs: AWG22, 2-pair Cable	OP ()	OMRON	2	XS5W-T421-DMC-K
			5	XS5W-T421-GMC-K
			10	XS5W-T421-JMC-K
			0.3	XS5W-T422-AMC-K
			0.5	XS5W-T422-BMC-K
Rugged type		OMBON	1	XS5W-T422-CMC-K
Cable with Connectors on Both Ends (M12 Right-angle/RJ45) Wire Gauge and Number of Pairs: AWG22, 2-pair Cable	<b>F</b> ()	UIVINUIN	2	XS5W-T422-DMC-K
			5	XS5W-T422-GMC-K
			10	XS5W-T422-JMC-K

Note: For details, refer to Cat.No.G019.

Rugged type cables length 0.3, 0.5, 1, 2, 3, 5, 10 and 15m are available.

<sup>\*1.</sup> Standard type cables length 0.2, 0.3, 0.5, 1, 1.5, 2, 3, 5, 7.5, 10, 15 and 20m are available.

<sup>\*2.</sup> The lineup features Low Smoke Zero Halogen cables for in-cabinet use and PUR cables for out-of-cabinet use.

<sup>\*3.</sup> Cables colors are available in blue, yellow, or Green.

#### **Cables / Connectors**

#### Wire Gauge and Number of Pairs: AWG24, 4-pair Cable

Item Appearance		Recommended manufacturer	Model	
	_	Hitachi Metals, Ltd.	NETSTAR-C5E SAB 0.5×4P *	
Cables	_	Kuramo Electric Co.	KETH-SB *	
	-	SWCC Showa Cable Systems Co.	FAE-5004 *	
RJ45 Connectors	-	Panduit Corporation	MPS588-C *	

<sup>\*</sup> We recommend you to use above cable and connector together.

#### Wire Gauge and Number of Pairs: AWG22, 2-pair Cable

		, .	
Item	Appearance	Recommended manufacturer	Model
Cables	-	Kuramo Electric Co.	KETH-PSB-OMR *
	_	JMACS Japan Co., Ltd.	PNET/B *
RJ45 Assembly Connector	Canal	OMRON	XS6G-T421-1 *

**Note:** Connect both ends of cable shielded wires to the connector hoods.

#### **Support Software**

	Specifications				
Product name		Number of licenses	Media	Model	Standards
FA Integrated Tool Package CX-One Ver. 4.□	The CX-One is a comprehensive software package that integrates Support Software for OMRON PLCs and components. CX-One runs on the following OS. OS: Windows XP (Service Pack 3 or higher, 32-bit version) / Windows Vista (32-bit/64-bit version) / Windows 7 (32-bit/64-bit version)/ Windows 8(32-bit/64-bit version)/ Windows 8.1 (32-bit/64-bit version) CX-One Version 4. includes CX-Programmer Ver.9. For details, refer to the CX-One catalog (Cat. No. R134).	1 license *	DVD	CXONE-AL01D-V4	-

<sup>\*</sup> Multi licenses are available for the CX-One (3, 10, 30 or 50 licenses).

<sup>\*</sup> We recommend you to use above cable and connector together.

## **Interpreting Model Numbers**

You can identify the number of axes and output pattern from the model number.

## **CJ1W-NC 281**

(1) (2) (3) (4)

No	Item	Symbol	Specifications	
(1)	C	J-series Po	sition Control Unit	
	2		2 axes	
(0)	) Number of axes	Number of axes	4	4 axes
(2)			8	8 axes
		F	16 axes	
(3)	Output pattern	8	EtherCAT	
(4)	Davidanment number	1	Servo control only	
(4)	Development number	2	Servo control + I/O communications	

### **Mountable Racks**

	NJ system		CJ system (CJ1, CJ2)		CP1H system	NSJ s	ystem
Model	CPU Rack	Expansion Rack	CPU Rack Expansion Backplane		CP1H PLC	NSJ Controller	Expansion Backplane
CJ1W-NC281 CJ1W-NC481 CJ1W-NC881 CJ1W-NCF81 CJ1W-NC482 CJ1W-NC482 CJ1W-NC882	Not Supported		16 Units max. (10	per Rack)	Not Supported	Not Supported	10 Units

## **General Specifications**

Item	CJ1W-NC281/-NC481/-NC881/-NCF81/-NC482/-NCF82
Dimensions	90 × 65 × 31 mm (H × D × W)
Weight	110 g max.
Internal current consumption	460 mA max. at 5 VDC
Ambient operating temperature	0 to 55°C
Applicable standards	Conforms to cULus and EC Directives.

**Note:** All other specifications conform to the general specifications of the CJ Series.

## Characteristics

						Models				
	Item			Servo co	ontrol only		Servo co	ntrol + I/O comm	unications	
			CJ1W-NC281	CJ1W-NC481	CJ1W-NC881	CJ1W-NCF81	CJ1W-NC482	CJ1W-NC882	CJ1W-NCF82	
Applicable	PLCs		CJ Series							
Settable un	it numbers		0 to F (unit number as a CPU Bus Unit)							
Maximum n	umber of Units		10 Units per R	ack, 16 Units pe	er PLC (Can be	used on Expans	sion Racks.)			
	Position Contro Memory Areas	ol Unit Control	25 words in CPU Bus Unit Area							
Allocated	Axis Operation	Memory Areas	43 words for ea Work, DM, or E		(2 + 12 output	words and 13 +	16 input words)	in specified wo	rds in the CIO,	
I/O words	Memory Opera	tion Memory Areas	7 words for each	ch task (3 outpu	t words and 4 in	put words) in sp	ecified words in	the CIO, Work, I	DM, or EM Area	
	I/O Memory Are	eas		-			inputs: 640 wo	naximum (Outpuords, communica cified words in the ea	tions status: 20	
Controllable	e Servo Drives *1		G5-series Serv	o Drives with B	uilt-in EtherCAT	Communication	ns			
Controllable	e encoder input t	terminal *2 *3		-			OMRON enco	der input termin	al GX-EC02□1	
Control met	hod		Control comma	ands using Ethe	erCAT communi	cation				
Number of	Number of controlled axes		2 axes	4 axes	8 axes	16 axes	4 axes	8 axes	16 axes	
Maximum command output speed		104 Mpps *4								
	Setting unit			eters, inches, or	degrees					
Control			×1, ×10, ×100,	×1,000, or ×10	,000					
units	Electronic gear	ratio *5			to 1,048,576/1, 4,294,967,295	,				
Positioning functions			Memory opera	tion or direct op	eration					
	Single axis	Position control	2 axes	4 axes	8 axes	16 axes	4 axes	8 axes	16 axes	
	control	Speed control	2 axes	4 axes	8 axes	16 axes	4 axes	8 axes	16 axes	
		Linear interpolation	2 axes max.	4 axes max.	4 axes max.	4 axes max.	4 axes max.	4 axes max.	4 axes max.	
	control	Circular interpolation	2 axes	2 axes	2 axes	2 axes	2 axes	2 axes	2 axes	
		Helical interpolation *3					3 axes	3 axes	3 axes	
	Memory	Maximum number of tasks	2	4	4 *6	4 *6	4	4 *6	4 *6	
	operation	Sequence functions	JUMP, FOR-N	EXT (50 layers/	task), PSET, ar	nd PRSET	,		<u>'</u>	
		Dwell timers	500/task, 0 to 10.00 s (Set in increments of 0.01 s.)							
Position	Data		-2,147,483,648	3 to 2,147,483,6	47 command u	nits *7				
command values	Number of posi	ition command values	500/task							
Speed command	Data *8				3,647 command 48 to 2,147,483,	d units/s ,647 command ι	units/s			
values	Number of speed	d command values	500/task							
Acceleration	Data		0 to 250,000 m	ns						
times	Number of acco	eleration times	500/task							
Deceleration	Data		0 to 250,000 m	ıs						
times	Number of dec	eleration times	500/task							
	Overrides		0.01% to 500.0	00% (Can be se	t for each axis.)	1				
	Software limits					nits (Can be set				
Auxiliary functions	Backlash comp	ensation			formed using th of the Servo Dr	e compensation ive.	function in the	Servo Drive. Th	e setting range	
	Torque Limits		Unit version 1.1 or earlier: Supports only the ability to enable or disable the torque limits by turning ON or OFF the command bits.  Unit version 1.3 or later: Supports the ability to change the torque limit data via the Memory Area / Synchronous Data Link in addition to the ability to enable or disable the torque limits by turning ON or OFF the command bits.							
Synchronous Data Link function							ides command data, torque rward data, limitation value a a CJ2H-CPU ides command			

			Models							
	Item			Servo co	ntrol only		Servo cor	ntrol + I/O commi	unications	
			CJ1W-NC281	CJ1W-NC481	CJ1W-NC881	CJ1W-NCF81	CJ1W-NC482	CJ1W-NC882	CJ1W-NCF82	
	Control cycle	Control cycle		0.5 ms when using 1 to 2 axes 1 ms when using 3 to 4 axes	0.5 ms when using 1 to 2 axes 1 ms when using 3 to 4 axes 2 ms when using 5 to 8 axes	0.5 ms when using 1 to 2 axes 1 ms when using 3 to 4 axes 2 ms when using 5 to 16 axes	0.5 ms when using 1 to 2 axes 1 ms when using 3 to 4 axes	0.5 ms when using 1 to 2 axes 1 ms when using 3 to 4 axes 2 ms when using 5 to 8 axes	0.5 ms when using 1 to 2 axes 1 ms when using 3 to 4 axes 2 ms when using 5 to 16 axes	
Control performance	Communications cycle		250 μs		250 µs when using 1 to 4 axes 500 µs when using 5 to 8 axes	250 µs when using 1 to 4 axes 500 µs when using 5 to 10 axes 1.0 ms when using 11 to 16 axes	250 μs	250 µs when using 1 to 4 axes 500 µs when using 5 to 8 axes	250 μs min. when using 1 to 4 axes 500 μs min. when using 5 to 10 axes 1.0 ms when using 11 to 16 axes	
	Starting time	Direct operation (high-speed PTP) *10	0.15 to 0.4 ms		0.15 to 0.4 ms when using 1 to 4 axes 0.15 to 0.8 ms when using 5 to 8 axes	0.15 to 0.4 ms when using 1 to 4 axes 0.15 to 0.8 ms when using 5 to 10 axes 0.15 to 1.2 ms when using 11 to 16 axes	0.15 to 0.4 ms	0.15 to 0.4 ms when using 1 to 4 axes 0.15 to 0.8 ms when using 5 to 8 axes	0.15 to 0.4 ms when using 1 to 4 axes 0.15 to 0.8 ms when using 5 to 10 axes 0.15 to 1.2 ms when using 11 to 16 axes	
		Direct operation (bits) *11	0.75 to 1.25 ms	1.25 to 2.25 ms	2.5 to 4.5 ms	3.0 to 5.0 ms	1.25 to 2.25 ms	2.5 to 4.5 ms	3.0 to 5.0 ms	
		Memory operation (linear interpolation) *11	1.75 to 2.25 ms	3.25 to 4.25 ms	6.5 to 8.5 ms	7.0 to 9.0 ms	3.25 to 4.25 ms	6.5 to 8.5 ms	7.0 to 9.0 ms	
		Communications port	EtherCAT port	× 1			•			
	Servo Drive	Output signals	The following of	external output s command bits a sit, Servo Lock B	re provided for e	each axis for Ser		l: Deviation Cou	nter Reset Bit,	
Control I/O	interface	Input signals	The following s	external input sig status flags are p ag, and Position	provided for eac	h axis for Servo	Drive control: 0	Origin Input Flag	, Servo Drive	
	External interface signals *12		6 signals (external origin signal, origin proximity signal, forward limit signal, reverse limit signal, emergency stop signal, and interrupt input signal) for each axis							

- \*1. A controllable Servo Drive is Servo Drive for which you can use the position control functions of the Position Control Unit.
- \*2. A controllable encoder input terminal is a slave for which you can use the encoder axis function of the Position Control Unit.
- \*3. Available with unit version 1.5 or later.
- \*4. This is the maximum speed command when converted to pulses.
- \*5. Command units can be set for each axis according to the electronic gear ratio and unit multiplier.
  \*6. Up to four axes can be controlled by each task.
- \*7. Setting is possible between -2,147,483,648 and 2,147,483,647 pulses.
- \*8. The command can be set to up to 104,857,600 pps when converted to pulses.
- \*9. This is the time from executing a command at the PLC until the command is output on EtherCAT communications. Execution for command bits is in the I/O refresh period.
  - The starting time depends on the control cycle, communications cycle, and operating conditions.
  - Refer to Position Control Units Operation Manual (Cat. No. W487) for details.
- \*10. The starting time applies when starting one axis with a special Position Control Unit instruction and a CJ2M or CJ2H CPU Unit with unit version 1.3 or later.
- \*11.These are the internal Position Control Unit processing times.
- \*12.Servo Drive inputs are used.

### **EtherCAT Communications Specifications**

	Characteristics									
Item		Servo co	ntrol only		Servo c	ontrol + I/O commu	inications			
	CJ1W-NC281	CJ1W-NC481	CJ1W-NC881	CJ1W-NCF81	CJ1W-NC482	CJ1W-NC882	CJ1W-NCF82			
Communications standard	IEC 61158 Type	12								
Physical layer	100Base-TX (IEE	100Base-TX (IEEE802.3)								
Connector	RJ45 shielded co	RJ45 shielded connector × 1								
Communications media	Category 5 or hig	Category 5 or higher (Recommended: cable with double, aluminum tape and braided shielding)								
Communications distance	100 m max. betw	100 m max. between nodes								
Topology	Daisy chain only	Daisy chain only *1								
EtherCAT Master Specifications	Class B (minimu	m master-CoE cor	npatible (no inform	nation service for S	SDO))					
Maximum number of slaves *2	2	4	8	16	68	72	80			
Node address setting range	1 to 2	1 to 4	1 to 8	1 to 16	1 to 4 and 17 to 80 *3	1 to 8 and 17 to 80 *3	1 to 16 and 17 to 80 *3			
Communications cycle *4	250 μs, 500 μs, 1	l ms, or 2 ms								
Process data	Fixed PDO mapp	ings specified for	the slaves are use	ed (set using Supp	ort Software).					
Mail box (CoE)		sages, SDO reque device parameter		es, and SDO inform	nation (Used for Po	osition Control Uni	t communications			
LED indicators	ECAT RUN × 1 ECAT ERR × 1 L/A (Link/Activity) × 1									
CiA402 drive profile *5	Cyclic synchror     Cyclic synchror     Touch probe fur     Torque limit fun	Cyclic synchronous position mode     Cyclic synchronous velocity mode     Cyclic synchronous torque mode     Touch probe function     Torque limit function								

<sup>\*1.</sup> Ethernet hubs cannot be used.

#### **Number of Remote I/O Connections**

The Position Control Unit has the memory of up to 640 bytes for inputs and 640 bytes for outputs to be used for PDO communications. The number of slaves that can be connected to the CJ1W-NC482/NC882/NCF82 is determined by the maximum memory size for PDO communications. The memory of the PDO communication is shared with the Servo Drives; therefore, the number of I/O slaves that can be connected changes with the number of G5 Series Servo Drive (number of use axes) that are connected to the Position Control Unit.

Number of Servo	Size used by	Remaining PDO memory s	communications ize (bytes)	Number of slaves that can be connected according to slave I/O size (guidelines)				
Drive axes	Servo Drive axes (bytes) *	IN	OUT	8 bytes of I/O (4 input and 4 output bytes)	16 bytes of I/O (8 input and 8 output bytes)	32 bytes of I/O (16 input and 16 output bytes)	64 bytes of I/O (32 input and 32 output bytes)	
0 axis	0	640	640	64	64	40	20	
1 axis	29	611	611	64	64	38	19	
2 axes	58	582	582	64	64	36	18	
4 axes	116	524	524	64	64	32	16	
8 axes	232	408	408	64	51	25	12	
16 axes	464	176	176	64	22	11	5	

<sup>\*</sup> The G5-series Servo Drives also use IN and OUT bytes. The factory default of the PDO communications size is 29 bytes.

<sup>\*2.</sup> This is the number of slaves, including Servo Drives and remote I/O slaves. The number of slaves that can be connected is limited. Refer to Number of Remote I/O Connections for details.

<sup>\*3.</sup> Node addresses 17 to 80 are reserved for remote I/O slaves.

<sup>\*4.</sup> The setting range depends on the number of slaves that are connected and the slave specifications. Refer to Position Control Units Operation Manual (Cat. No. W487) for details.

<sup>\*5.</sup> This drive profile is used when connected to a G5-series Servo Drive.

## **Functional Specifications**

The following functions are supported when the Position Control Unit is connected to an EtherCAT-compatible OMNUC G5-series Servo Drive.

	Functi	on	Description		
		Absolute movements	Positioning is performed by specifying the absolute or relative target position and target speed directly from		
		Relative movements	the ladder program.		
		Speed control	Feeding at a specified speed is performed by specifying the target speed directly from the ladder program. Speed control is implemented using speed feeding with position control.		
	Single axis control	Interrupt feeding	Interrupt feeding can be used to move a specified amount when an interrupt input is received during an absolute movement, a relative movement, or speed control.		
		Rotation axis control	Rotation axes that are suitable for feeder and index table control can be controlled. Forward and reverse positioning and shortest route operations are possible.		
		Changing target positions and target speeds	The target position or target speed can be changed during an absolute movement, a relative movement, or speed control.		
Control functions		Linear interpolation	The operation of more than one axis is started and stopped simultaneously to move in a straight line to the target position from the starting point of each axis. Linear interpolation is possible for up to four axes.		
iunctions	Multi-axis control	Circular interpolation	The operation of any two axes is controlled to move in a circular arc.  Any of three methods can be used to specify a circular arc: specifying the target position and center point, specifying the target position, radius, and direction and specifying the target position and passing point.		
		Helical interpolation	Helical interpolation is performed by giving one more axis to circular interpolation. The number of turns can be specified.		
			This function is available with CJ1W-NC□82 (unit version 1.5 or later).  The target positions, speeds, and operation patterns can be set in advance in the Position Control Unit to		
		Automatic continuous operation	automatically perform a series of operations.  Continuous positioning and speed changes are also possible.		
	Memory operation	Sequence functions	Memory operation data provides sequence functions, including repetition of a given operation and starting/stopping operation data by using external inputs.  Therefore, the Position Control Unit can perform various operation sequences without affecting the ladder		
	Origin searches		programming in the CPU Unit.  External sensors and other means are used to detect the mechanical origin of the system.  You can select the origin search operation that is best for your system from 15 different origin search		
	Origin retur	ns	operation patterns.  You can return to the point that was defined as the mechanical origin.		
Manual		he present position	The present position can be changed to a specified value to define the origin.		
operation	Deceleration stops and emergency stops		An axis that is in operation can be decelerated to a stop or stopped immediately.		
	Jogging		You can jog either forward or in reverse.		
	Inching		You can inch either forward or in reverse.		
Synchronous	s Data Link		The CJ1W-NC 82 (unit version 1.3 or later) can perform data exchange between the CPU and Position Control Unit at regular intervals when used in conjunction with a CJ2H CPU (unit version 1.4 or later). In addition, you can use this function to perform synchronous feeding position, synchronous feeding velocity and synchronous feeding torque control. Also, optional commands are available for torque feedforward data torque limit data, and velocity limitation value.  CJ1W-NC 82 (unit version 1.5 or later) supports command for electronic cam operation as well.		
	Command u	ınit setting	You can set the unit of control for each axis according to the machine.		
		Automatic acceleration/ deceleration control	The acceleration/deceleration curve can be automatically created during operation. You can select either trapezoidal curve or an S curve based on a tertiary function.		
	Acceleration/ deceleration	Changing acceleration/ deceleration rates	You can change the rate of acceleration/deceleration during acceleration/deceleration.		
	control	Switching acceleration/ deceleration points	You can select one of three methods to connect speeds between different operation patterns during continuous memory operation.		
	Overrides		You can increase or decrease the operating speed of the system by a specified factor.		
	Backlash co	mpensation	You can compensate for mechanical play using a parameter.		
	M codes		M codes can be output during memory operation to interlock with external devices.		
	Zone setting	js	You can set zones and assess when the present position is in a zone. Up to three zones can be set for each axis.		
Auxiliary	Support for	absolute encoders	You can build an absolute positioning system by using a Servomotor with an Absolute Encoder. The Positior Control Units can be used together with OMRON's G5-series Servomotors with Absolute Encoders.		
control functions	Teaching		You can save the present position as position data for memory operation. You can use either the command present position or feedback present position.		
	Torque limit	outputs	The torque limit outputs can be used to switch the torque limits of the Servo Drive. They can be turned OI and OFF directly from a ladder program. Torque limits can be automatically switched by using holding for a origin search operation.  In addition, you can change the torque limit data via the Synchronous Data Link by using the CJ1W-NC□8 (unit version 1.3 or later) in conjunction with a CJ2H-CPU (unit version 1.4 or later) and G5-series Servo Driv (version 2.0 or later).  Also, you can change the torque limit data via the Memory Area by using the CJ1W-NC□81/-NC□82 (un version 1.3 or later) in conjunction with a G5-series Servo Drive (version 2.0 or later).		
		Software limits	You can set forward and reverse software limits for axis operation.  If the target position exceeds a software limit, it will be detected in the command value check that is performed at startup.		
	Monitoring functions	Monitoring position/ speed deviations	The Position Control Unit monitors the position or speed deviation between the present command position and present feedback position. You can stop axis operation if the deviation is too large.		
		Monitoring deviation	The deviation between axes is also monitored during linear interpolation. You can stop axis operation if the		
		between axes	deviation is too large.		


Functions available when connected with OMRON encoder input terminal GX-EC02 $\square$ 1 are as shown below. They are available with CJ1W-NC $\square$ 82, unit version 1.5 or later.

Function		Description
Manual operation	Present position preset	The present position can be changed to a specified value to define the origin.
	Command unit setting	You can set the unit of control for each axis according to the machine.
Auxiliary	Zone settings	You can set a zone to check if the present position is in the set zone. Up to three zones can be set for each axis.
control functions	Present position latch	The position data when an external control input (latch A) is detected at the encoder input terminal is stored in the Position Control Unit.
	Origin position latch	The position data when an external control input (latch B) is detected at the encoder input terminal is stored in the Position Control Unit.

### **External Interface**

#### **Part Names**

CJ1W-NC281/-NC481/-NC881/-NCF81/-NC482/-NC882/-NCF82



#### **Indicators**

Indicator	Display color	Status	Description
		ON	Normal operation.
RUN Green		OFF	The power supply is OFF, a hardware error has occurred, or the PLC has detected a Position Control Unit error.
ERC	Red	ON	An error has occurred.
Enc	neu	OFF	Other than the above
ERH	Red	ON	There is an error in the PLC.
ENFI	neu	OFF	Other than the above
		OFF	Initialized state
ECAT RUN	Green	Blinking	Pre-Operational state
LOAT HON		Single flash	Safe-Operational state
		ON	Operational state
		OFF	No error
		Blinking	Communications setting error
		Single flash	Synchronization error or communications data error
ECAT ERR	Red	Double flash	Application WDT timeout
		Flickering	Boot error
		ON	PDI WDT timeout
		OFF	Link not established in physical layer.
ECAT L/A	Green	ON	Link established in physical layer.
		Flickering	In operation after establishing link.

#### **EtherCAT Communications Connector**

This connector is used to connect the EtherCAT twisted-pair cable.

#### **Connector Specifications**

Specification	Description		
Electrical characteristics	Conforms to IEEE 802.3 standards.		
Connector structure	RJ45 8-pin modular connector (Conforms to ISO 8877.)		

#### **Pin Assignments**

	Pin No.	Signal name	Abbreviation	Signal direction
	1	Transmission data +	TD+	Output
	2	Transmission data -	TD-	Output
	3	Reception data +	RD+	Input
<b>□</b> \	4	Not used.		
	5	Not used.		
	6	Reception data -	RD-	Input
	7	Not used.		
	8	Not used.		
	Hood	Frame ground	FG	

#### **EtherCAT Communications Cables**

Use a category 5 or higher cable with double, aluminum tape and braided shielding.

Note: The maximum distance between any two nodes is 100 m. Some cables, however, are not rated for 100 m. Generally speaking, the transmission performance of stranded wires is worse than that of solid wire. Cables with stranded wires generally are not rated for 100 m.

#### **Connector (Modular Plug) Specifications**

Use a category 5 or higher, shielded connector.

Note: When selecting a connector, make sure that it is suitable for the cable that you are using. The following items must be confirmed: conductor size, whether connector is solid or stranded wire, whether there are 2 wire pairs or 4, the outside diameter, etc.

### **Unit Versions and Programming**

#### **Unit Versions**

O: Exist, ---: Does not exist

Unit	Model		Unit Versions				
Onit	Wodei	Ver. 1.0	Ver. 1.1	Ver. 1.3	Ver. 1.4	Ver. 1.5	
	CJ1W-NC281	0	0	0	0	0	
	CJ1W-NC481	0	0	0	0	0	
	CJ1W-NC881	0	0	0	0	0	
Position Control Units with EtherCAT	CJ1W-NCF81		0	0	0	0	
	CJ1W-NC482		0	0	0	0	
	CJ1W-NC882		0	0	0	0	
	CJ1W-NCF82			0	0	0	
Compatible CX-Programmer version		Version 9.11 or higher	Version 9.12 or higher	Version 9.32 or higher	Version 9.52 or higher *	Version 9.60 or higher	

<sup>\*</sup> Check *CX-One Information*. The Common Components must be 2014.09 (September 2014) or later.

## Function Support According to Unit Versions CJ1W-NC□81

O: Supported, ---: Not supported

Finalities	Unit Versions				
Function	Ver. 1.0	Ver. 1.1	Ver. 1.3	Ver. 1.4	Ver. 1.5
Status Word Expanded Monitor Type		0	0	0	•
I/O communications as type of slave that can be connected		0	0	0	0
Enabling/disabling registered slaves		0	0	0	•
Clearing input data to zero when there is a communications error with a remote $\ensuremath{\mathbb{I}}$ O slave		•	•	•	0
Electronic gear ratio setting range expansion			•	0	0
Origin position latch			0	0	0
Ad hoc change of torque limit data using Allocated Memory Areas *1			•	0	0
Ad hoc change of torque limit data/torque feedforward data using the Synchronous Data Link *1 *2					
Synchronous Data Link (Electric Shaft function) *1 *2					
Synchronous Data Link (Synchronous feeding velocity function) *1 *2					
Synchronous Data Link (Synchronous feeding torque function) *1 *2					
Absolute Encoder Origin Establishment Timing Setting				•	0
Electronic cam operation					
Encoder axis					
Helical interpolation					

<sup>\*1.</sup> Whether or not this function is supported depends on the version of the G5-series Servo Drive. For details, refer to "Function Support According to G5-series Servo Drive Versions".

#### CJ1W-NC□82

O: Supported, ---: Not supported

Function	Unit Versions				
Function	Ver. 1.0	Ver. 1.1	Ver. 1.3	Ver. 1.4	Ver. 1.5
Status Word Expanded Monitor Type		0	0	0	0
I/O communications as type of slave that can be connected		0	0	0	0
Enabling/disabling registered slaves		0	0	0	0
Clearing input data to zero when there is a communications error with a remote $\ensuremath{I}/\ensuremath{O}$ slave		•	•	•	0
Electronic gear ratio setting range expansion			0	0	0
Origin position latch			0	0	0
Ad hoc change of torque limit data using Allocated Memory Areas *1			0	0	0
Ad hoc change of torque limit data/torque feedforward data using the Synchronous Data Link *1 *2			•	•	0
Synchronous Data Link (Electric Shaft function) *1 *2			0	0	0
Synchronous Data Link (Synchronous feeding velocity function) *1 *2			0	0	0
Synchronous Data Link (Synchronous feeding torque function) *1 *2			0	0	0
Absolute Encoder Origin Establishment Timing Setting				0	0
Electronic cam operation					0
Encoder axis					0
Helical interpolation					0

<sup>\*1.</sup> Whether or not this function is supported depends on the version of the G5-series Servo Drive. For details, refer to "Function Support According to G5-series Servo Drive Versions".

<sup>\*2.</sup> Whether or not this function is supported depends on the version of the G5-series Servo Drive. For details, refer to "Function Support According to CPU Unit Versions".

<sup>\*2.</sup> Whether or not this function is supported depends on the version of the G5-series Servo Drive. For details, refer to "Function Support According to CPU Unit Versions".

## **Function Support According to G5-series Servo Drive Versions**

As indicated in the table below, functions supported by CJ1W-NC\B2 Position Control Units (unit version 1.3 or later) differ depending on the version of the G5 series serve drive used in conjunction with the Position Control Unit:

O: Supported, ---: Not supported

Function		Drive version		
		Ver. 1.□	Ver. 2.0 or later	
Synchronous Data Link function	Synchronous Feeding Position (Electric Shaft) function	0	•	
(Synchronous feeding functions)	Synchronous Feeding Velocity function		<b>O</b>	
	Synchronous Feeding Torque function		O	
Ad hoc change of torque limit data by use of Allocated Memory Areas			<b>O</b>	
Ad hoc change of torque limit data / torque feedforward data by use of the Synchronous Data Link			O	

## **Function Support According to CPU Unit Versions**

As indicated in the table below, functions supported by CJ1W-NC\B2 Position Control Units (unit version 1.3 or later) differ depending on the version of the CPU unit used in conjunction with the Position Control Unit:

 $\Omega$ : Supported,  $\Delta$ : Limited, ---: Not supported

	Function	CJ	CJ1-H/CJ1/ CJ1M/CJ2M	
	Fullction	Ver. 1.3 or earlier Ver. 1.4 or later		
	Synchronous Feeding Position (Electric Shaft) function *	Δ*	•	Δ*
Synchronous Data Link function (Synchronous feeding functions)	Electronic cam operation	Δ*	0	Δ*
(Synchronous feeding functions)	Synchronous Feeding Velocity function		0	
	Synchronous Torque Command function		0	
Ad hoc change of torque limit data / torque feedforward data by use of the Synchronous Data Link			0	

<sup>\*</sup> Available with CJ1W-NC 82, unit version 1.5 or later. Note that Synchronous Data Link output cannot be set as an auxiliary axis. If it is set, the value of auxiliary axis will always be 0.

## **Function List of Function Block Library (FBL)**


## **Omron FB (Function Block Library)**


1	Move Absolute	14	Read Status		
2	Unlimited Move Absolute	15	Read Parameter		
3	Move Relative	16	Read Error		
4	Speed Control	17	Read Present Position		
5	Origin Search	18	Present Position Latch		
6	Origin Return	19 Write Parameter			
7	Deceleration Stop	20 Save Parameter			
8	Operation Command	21	Teaching		
9	Error Reset	22	Present Position Preset		
10	Deviation Counter Reset	23	Override Setting		
11	Run Program	24 Torque Limits			
12	Interrupt Feeding	25	Absolute Encoder Setup		
13	Jogging / Inching	26	Absolute Encoder's Origin Position Offset Setting		

Dimensions (Unit: mm)

#### CJ1W-NC281/-NC481/-NC881/-NCF81/-NC482/-NC882/-NCF82







## **Related Manuals**

Manual	Cat. No.	Model	Application	Description	
CJ-series Position Control Unit Operation Manual	W487	CJ1W-NC281 CJ1W-NC481 CJ1W-NC881 CJ1W-NCF81 CJ1W-NC482 CJ1W-NC882 CJ1W-NCF82	Information on CJTW-NC281/-NC481/ -NC881/-NCF81/-NC482/ -NC882/-F82 Position Control Units	Describes the setting and application procedures for the Position Control Units.	
CX-Programmer Operation Manual	W446	CXONE-AL C-V	Support Software for Windows computers CX-Programmer operating procedure	Describes operating procedures for the CX-Programmer.	

#### Terms and Conditions Agreement

#### Read and understand this catalog.

Please read and understand this catalog before purchasing the products. Please consult your OMRON representative if you have any questions or comments.

#### Warranties.

- (a) Exclusive Warranty. Omron's exclusive warranty is that the Products will be free from defects in materials and workmanship for a period of twelve months from the date of sale by Omron (or such other period expressed in writing by Omron). Omron disclaims all other warranties, express or implied.
- (b) Limitations. OMRON MAKES NO WARRANTY OR REPRESENTATION, EXPRESS OR IMPLIED, ABOUT NON-INFRINGEMENT, MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE OF THE PRODUCTS. BUYER ACKNOWLEDGES THAT IT ALONE HAS DETERMINED THAT THE

PRODUCTS WILL SUITABLY MEET THE REQUIREMENTS OF THEIR INTENDED USE.

Omron further disclaims all warranties and responsibility of any type for claims or expenses based on infringement by the Products or otherwise of any intellectual property right. (c) Buyer Remedy. Omron's sole obligation hereunder shall be, at Omron's election, to (i) replace (in the form originally shipped with Buyer responsible for labor charges for removal or replacement thereof) the non-complying Product, (ii) repair the non-complying Product, or (iii) repay or credit Buyer an amount equal to the purchase price of the non-complying Product; provided that in no event shall Omron be responsible for warranty, repair, indemnity or any other claims or expenses regarding the Products unless Omron's analysis confirms that the Products were properly handled, stored, installed and maintained and not subject to contamination, abuse, misuse or inappropriate modification. Return of any Products by Buyer must be approved in writing by Omron before shipment. Omron Companies shall not be liable for the suitability or unsuitability or the results from the use of Products in combination with any electrical or electronic components, circuits, system assemblies or any other materials or substances or environments. Any advice, recommendations or information given orally or in writing, are not to be construed as an amendment or addition to the above warranty.

See http://www.omron.com/global/ or contact your Omron representative for published information.

#### Limitation on Liability; Etc.

OMRON COMPANIES SHALL NOT BE LIABLE FOR SPECIAL, INDIRECT, INCIDENTAL, OR CONSEQUENTIAL DAMAGES, LOSS OF PROFITS OR PRODUCTION OR COMMERCIAL LOSS IN ANY WAY CONNECTED WITH THE PRODUCTS, WHETHER SUCH CLAIM IS BASED IN CONTRACT, WARRANTY, NEGLIGENCE OR STRICT LIABILITY.

Further, in no event shall liability of Omron Companies exceed the individual price of the Product on which liability is asserted.

#### Suitability of Use.

Omron Companies shall not be responsible for conformity with any standards, codes or regulations which apply to the combination of the Product in the Buyer's application or use of the Product. At Buyer's request, Omron will provide applicable third party certification documents identifying ratings and limitations of use which apply to the Product. This information by itself is not sufficient for a complete determination of the suitability of the Product in combination with the end product, machine, system, or other application or use. Buyer shall be solely responsible for determining appropriateness of the particular Product with respect to Buyer's application, product or system. Buyer shall take application responsibility in all cases.

NEVER USE THE PRODUCT FOR AN APPLICATION INVOLVING SERIOUS RISK TO LIFE OR PROPERTY OR IN LARGE QUANTITIES WITHOUT ENSURING THAT THE SYSTEM AS A WHOLE HAS BEEN DESIGNED TO ADDRESS THE RISKS, AND THAT THE OMRON PRODUCT(S) IS PROPERLY RATED AND INSTALLED FOR THE INTENDED USE WITHIN THE OVERALL EQUIPMENT OR SYSTEM.

#### Programmable Products.

Omron Companies shall not be responsible for the user's programming of a programmable Product, or any consequence thereof.

#### Performance Data.

Data presented in Omron Company websites, catalogs and other materials is provided as a guide for the user in determining suitability and does not constitute a warranty. It may represent the result of Omron's test conditions, and the user must correlate it to actual application requirements. Actual performance is subject to the Omron's Warranty and Limitations of Liability.

#### Change in Specifications.

Product specifications and accessories may be changed at any time based on improvements and other reasons. It is our practice to change part numbers when published ratings or features are changed, or when significant construction changes are made. However, some specifications of the Product may be changed without any notice. When in doubt, special part numbers may be assigned to fix or establish key specifications for your application. Please consult with your Omron's representative at any time to confirm actual specifications of purchased Product.

<u>Errors and Omissions.</u> <u>Information presented by Omron Companies has been checked and is believed to be accurate; however, no responsibility is accurate.</u> assumed for clerical, typographical or proofreading errors or omissions.

2016.4

In the interest of product improvement, specifications are subject to change without notice.

